LUBRICATION CHART

KEY TO LUBRICATION CHART

DAILY

(1) ENGINE. Inspect the oil level, and top up if necessary with oil to Ref. A.

AFTER THE FIRST 500 MILES (800 Km.)

(2) ENGINE. Drain off the old oil and refill with fresh oil to Ref. A.

(3) GEARBOX. Drain off the old oil and refill with fresh oil to Ref. A.

(4) REAR AXLE. Drain off the old oil and refill with fresh oil to Ref. B.

EVERY 1,000 MILES (1600 Km.)

(5) GEARBOX. Top up if necessary to the filler plug level with oil to Ref. A.

(6) REAR AXLE. Top up if necessary to the filler plug level with oil to Ref. B.

(7) STEERING TIE-ROD BALL JOINTS (2 nipples). Give three or four strokes of a gun filled with lubricant to Ref. C.

(8) SWIVEL AXLES AND SUSPENSION LOWER JOINTS (6 nipples). Give three or four strokes of a gun filled with lubricant to Ref. C.

(9) PROPELLER SHAFT (2 nipples). Give three or four strokes of a gun filled with lubricant to Ref. C.

(10) HAND BRAKE CABLE (1 nipple). Give three or four strokes of a gun filled with **grease** to Ref. C.

(11) HAND BRAKE COMPENSATOR LEVER (1 nipple). Give three or four strokes of a gun filled with lubricant to Ref. C.

(12) HAND BRAKE LINKAGE JOINTS. Lubricate with an oilcan filled with oil to Ref. D.

(13) CLUTCH, BRAKE, AND THROTTLE JOINTS. Lubricate with an oilcan filled with oil to Ref. D.

(14) CARBURETTERS. Top up damper assembly reservoirs with oil to Ref. D.

EVERY 3,000 MILES (4800 Km.)

(15) ENGINE. Drain off the old oil and refill with fresh oil to Ref. A.

EVERY 6,000 MILES (9600 Km.)

(16) DISTRIBUTOR. Withdraw the rotor arm and add a few drops of oil to Ref. D to the cam bearing and to the advance mechanism through the gap around the cam spindle. Lightly smear the cam with grease to Ref. C.

(17) OIL FILTER. Wash the bowl in fuel and fit a new element.

(18) GEARBOX. Drain off the old oil and refill with fresh oil to Ref. A.

(19) REAR AXLE. Drain off the old oil and refill with fresh oil to Ref. B.

(20) WATER PUMP. Remove the plug and add a few drops of S.A.E. 140 oil; replace the plug.

(21) FRONT HUBS. Remove the front hub discs and prise off the grease-retaining caps from the ends of the hubs. Fill the caps with **grease** to Ref. C and replace securely.

EVERY 12,000 MILES (19200 Km.)

(22) STEERING-RACK. Apply the grease gun filled with oil to Ref. B to the nipple on the steering rack and give 10 strokes only.

(23) DYNAMO. Unscrew the lubricator cap, remove the felt pad and spring, and half-fill the cup with **grease** to Ref. C.

MULTIGRADE MOTOR OILS

In addition to the lubricants recommended in this Manual we approve the use of the multigrade motor oils produced by the oil companies shown in our publications for all climatic temperatures unless the engine is in poor mechanical condition.

LUBRICATION CHART

