A

B

C

A

MIDGET

RIGHT HAND SILL

MIDGET

LEFT HAND SILL

MG MIDGET SILL BADGE GUIDE SET

Fitting Instructions

Thoroughly clean the front area of the sill, removing all traces of grease and dirt to allow better adhesion of the masks.

•

Carefully cut along dotted lines A, B and C.

Note: The lines are guides for the leading and lower edges of the sills, enabling accurate positioning.

•

Remove the backing paper and align the appropriate mask with the leading and lower edges of the sill.

•

Apply firmly, taking care to avoid wrinkles and bubbles.

Note: The Midget sill curves at the front edge (following the line of the wheel arch). The mask should be aligned with the very leading edge of the curve.

•

Mark each cross using a sharp centre punch.

•

Drill using a 1mm drill as a guide, enlarging the hole in stages, using a 2mm and then a 4mm drill.

•

Remove mask, fit the plastic clips and badge components.

Tools Required

Scissors
Centre punch
Hammer
Hand drill
Drills: 1mm, 2mm, 4mm.

Helpful Hints

This MG Midget mask offers an accurate guide to drilling, but for best results please note the following: -

Use a sharp centre punch and hammer for accurate drill guidance.

Use a hand drill rather than an electric drill for greater control and accuracy.

Paint bare metal to protect against rust.

BRITISH MOTOR HERITAGE
© 1996