TOOL KIT

Item No.	DESCRIPTION	Commencing (C) 501 Part Number	Illus. No.	Qty. per Vehicle RHD	Qty. per Vehicle LHD	Unit of Issue	Type of Vehicle	MODIFICATIONS New Part Number	MODIFICATIONS Change Point	MODIFICATIONS PAU No.	REMARKS
1	**Jack—lifting**	**2A5472**		**1**	**1**						
2	Spanner—ratchet—jack	2A5627		1	1						
3	Pump—tyre	3H2274		1	1						
4	Gun—grease	13H50		1	1						
5	Brace—wheel	2A5626		1	1						
6	Screwdriver and gauge—ignition	3H2648		1	1						
7	Spanner—tyre valve	2H1683		1	1						
8	Spanner—box—sparking plug	2A5379		1	1						
9	Gauge—feeler—tappet and sparking plug	2A5419		1	1						
10	Screwdriver	2H4614		1	1						
11	Bag—tool	2A5412		1	1						

Item No.	DESCRIPTION	Commencing (C) 501 Part Number	Illus. No.	Qty. per Vehicle RHD	Qty. per Vehicle LHD	Unit of Issue	Type of Vehicle	MODIFICATIONS New Part Number	MODIFICATIONS Change Point	MODIFICATIONS PAU No.	REMARKS
	SERVICE TOOLS										
	ENGINE										
1	Reamer—camshaft liner **(Basic tool)**	18G123A		1	1						
2	Pilot—camshaft liner reamer (small)	18G123AJ		1	1						
3	Pilot—camshaft liner reamer (large)	18G123AH		1	1						
4	Cutter—camshaft liner reamer	18G123AN		1	1						Correction, was 18G123W
5	Remover and replacer—camshaft liner **(Basic tool)**	18G124A		1	1						
6	Adaptor—camshaft liner remover	18G124K		1	1						
7	Remover—crankshaft gear and pulley	18G2		1	1						
8	Replacer—crankshaft gear and pulley	18G138		1	1						
9	Grinding-in tool—oil pump release valve	18G69		1	1						
10	Compressor—piston ring	18G55A		1	1						
11	Spanner—starting nut	18G98		1	1						
12	Remover and replacer—valve rocker bush	18G226		1	1						
13	Drift—valve rocker bush remover and replacer	18G226A		1	1						
14	Cutter—valve seat finishing	18G167		1	1						
15	Breaker—valve seat glaze	18G167A		1	1						
16	Cutter—top—valve seat narrowing	18G167B		1	1						
17	Cutter—bottom—valve seat narrowing	18G167C		1	1						
18	Pilot—valve seat cutter	18G167D		1	1						
19	Handle—valve seat cutter and pilot	18G27		1	1						
20	Compressor—valve spring	18G45		1	1						
21	Pad—suction—valve grinding-in tool	18G29B		1	1						
22	Adaptor—radiator reverse-flush	18G187		1	1						
	CLUTCH										
23	Clutch assembly gauging fixture	18G99A		1	1						
24	Plate centralizer	18G139		1	1						
	GEARBOX										
25	Synchromesh unit assembly ring	18G144		1	1						
26	Dummy layshaft	18G471		1	1						
27	Remover—oil seal **(Basic tool)**	18G389		1	1						
28	Adaptor—oil seal remover	18G389A		1	1						
29	Adaptor—oil seal replacer	18G134L		1	1						
30	Replacer—first motion shaft assembly	18G140		1	1						
31	Replacer—needle-roller bearing	18G194		1	1						
32	Clinching tool—oil seal—gearbox extension	18G488		1	1						
33	Replacer—bearing and oil seal	18G134		1	1						


Item No.	DESCRIPTION	Commencing (C) 501 Part Number	Illus. No.	Qty. per Vehicle RHD	Qty. per Vehicle LHD	Unit of Issue	Type of Vehicle	MODIFICATIONS New Part Number	MODIFICATIONS Change Point	MODIFICATIONS PAU No.	REMARKS
	Service Tools—*continued*										
	REAR AXLE AND REAR SUSPENSION										
1	Gauge—bevel pinion setting	18G191		1	1						
2	Remover—bevel pinion bearing outer race **(Basic tool)**	18G264		1	1						
3	Adaptor—bevel pinion bearing outer race remover (front)	18G264E		1	1						
4	Adaptor—bevel pinion bearing outer race remover (rear)	18G264D		1	1						
5	Gauge—preload—bevel pinion bearing	18G207		1	1						
6	Remover and replacer—bevel pinion inner race	18G285		1	1						
7	Wrench—bevel pinion flange	18G34A		1	1						
8	Gauge—differential bearing	18G191A		1	1						
9	Remover—differential bearing **(Basic tool)**	18G47C		1	1						
10	Adaptor—differential bearing remover	18G47M		1	1						
11	Adaptor—rear hub replacer	18G134Q		1	1						
12	Remover—rear hub	18G146		1	1						
13	Replacer—rear hub bearing	18G4		1	1						
14	Replacer—bevel pinion and rear hub oil seal	18G14		1	1						
15	Spanner—rear hub nut	18G152		1	1						
16	Replacer—bearing and oil seal **(Basic tool)**	18G134		1	1						
	FRONT SUSPENSION										
17	Front suspension assembly fixture	18G253		1	1						
18	Remover—front hub	18G146		1	1						
19	Remover—front hub outer bearing	18G7		1	1						
20	Adaptor—front hub bearing inner race remover	18G8P		1	1						Use with 18G8
21	Remover—front hub bearing outer race **(Basic tool)**	18G260		1	1						
22	Adaptor—front hub bearing outer race remover	18G260A		1	1						
23	Adaptor—front hub bearing outer race remover	18G260B		1	1						
24	Adaptor—front hub outer bearing replacer	18G134B		1	1						
25	Adaptor—front hub inner bearing replacer	18G134C		1	1						
26	Remover and replacer—swivel axle bush	18G154		1	1						
27	Swivel axle broaching equipment	18G155		1	1						
28	Guide—swivel axle bush broach	18G155A		1	1						
29	Compressor—front suspension spring	18G153		1	1						
30	Replacer—bearing and oil seal **(Basic tool)**	18G134		1	1						
	STEERING										
31	Pin spanner—tie-rod	18G312		1	1						
32	'C' spanner—tie-rod	18G313		1	1						
33	Spanner—steering wheel nut	18G562		1	1						
	MISCELLANEOUS										
34	Wrench—torque	18G372		1	1						

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	PAU No.	
	LITERATURE										
1	Service Parts List	AKD829		1	1						
2	Operation Manual	97H1583A		1	1						
3	Workshop Manual	97H1585		1	1						
4	Price List	AKD693		1	1						
5	Schedule of Repair Charges (U.K.)	AKD876A		1	1						
6	Schedule of Repair Times	AKD877		1	1						
7	Maintenance Service Voucher Booklet	97H1636A		1	1						
8	Special Tuning Booklet	AKD1021		1	1						
9	Service Tool Catalogue	AKD770		1	1						
10	Service Literature Catalogue	AKD858D		1	1						


HEATER

(Optional Extra)

Item No.	DESCRIPTION	Commencing (C) 501 Part Number	Illus. No.	Qty. per Vehicle RHD	Qty. per Vehicle LHD	Unit of Issue	Type of Vehicle	MODIFICATIONS New Part Number	MODIFICATIONS Change Point	MODIFICATIONS PAU No.	REMARKS
1	**Heater kit**	**8G9023**		**1 set**	**1 set**	1					
2	**Heater unit assembly** (R)	**13H54**		**1**	**1**						
3	Radiator and seals (R)	17H1590	1	1	1						
4	Tube—inlet	17H1592	2	1	1						
5	Plate (front)	17H1594	3	1	1						
6	Plate (rear)	17H1596	4	1	1						
7	Grommet	17H1591	5	2	2						
8	Screw	17H1593	6	3	3						
9	Clip	17H1595	7	10	10						
10	Seal—heater base	4B9713	8	1	1						
11	Screw—heater to platform	PMZ0408	9	4	4						
12	Washer for screw (plain)	PWZ104	10	4	4	12					
13	Washer for screw (spring)	LWZ204	11	4	4						
14	Hose—heater to control valve	AHA5213	12	1	1						
15	Hose—water outlet	AHA5212	13	1	1						
16	Cutter—hose	N.S.P.		1	1						] For service purposes use
17	Connector—adaptor—control tap	N.S.P.		1	1						] 1 off 2A2084 hose—
18	Hose—radiator hose to heater outlet pipe	N.S.P.		1	1						] radiator to pump
19	Pipe—heater outlet to radiator	AHA5214	14	1	1						
20	Setscrew—heater outlet pipe clip to inlet manifold	ZCS0404		2	2						
21	Washer for setscrew (plain)	PWZ104		2	2						
22	Washer for setscrew (spring)	LWZ204		2	2						
23	Plate—heater instruction	4G6826	15	1	1						
24	Clip—hose	8G531	16	6	6						
25	**Tap—water control**	**ACA5455**	**17**	**1**	**1**						**Correction, was 17H1631**
26	Plate—adaptor—control tap	ACA5456	18	1	1						
27	Joint—control tap to cylinder head	1G2342	19	1	1	12					
28	Washer for tap	2K5629	20	2	2						
29	Screw—tap to cylinder head	HZS0406	21	2	2						
30	**Switch assembly—heater**	**13H55**	**22**	**1**	**1**						
31	Knob	17H1602	23	1	1						
32	Pin for knob	17H1603	24	1	1						
33	Clip for knob	17H1601	25	1	1						
34	Cable (inner)	17H1599	26	1	1						
35	Trunnion	14G6451	27	1	1						
36	Screw—trunnion	AHH5593	28	1	1						
37	Trunnion—control cable	AHH5439		1	1						
38	Screw for trunnion	AHH5593		1	1						
39	Connector—snap (switch to blower)	17H1634	29	1	1						




To face page S.5




To face page S.6

Item No.	DESCRIPTION	Commencing (C) 501 Part Number	Illus. No.	Qty. per Vehicle RHD	Qty. per Vehicle LHD	Unit of Issue	Type of Vehicle	MODIFICATIONS New Part Number	MODIFICATIONS Change Point	MODIFICATIONS PAU No.	REMARKS
	Heater—*continued*										
1	**Blower assembly** ..... **(R)**	**13H51**		**1**	**1**						
2	Motor ..... (R)	17H1455	30	1	1						
3	Rotor	17H1574	31	1	1						Correction, was 17H1598
4	Casing	17H819	32	1	1						
5	Mesh—intake	17H1597	33	1	1						
6	Grommet	24K2085	34	3	3						Correction, was 17H1292
7	Screw—blower assembly to foot-well top	PMZ0408	35	3	3						
8	Washer for screw (plain)	PWZ104	36	3	3	12					
9	Washer for screw (spring)	LWZ204	37	3	3						
10	**Plate—inlet flange**	**14A4763**	**38**	**1**	**1**						
11	Screw—plate to radiator and wheel arch bracket....	PMZ0408	39	1	1						
12	Washer for screw (plain)	PWZ104	40	1	1	12					
13	Nut for screw.....	FNZ104	41	1	1						
14	**Hose—blower to inlet flange**	**13H53**	**42**	**1**	**1**						
15	Clip—hose to blower and inlet flange	14G800	43	2	2						
16	Clip—hose to wheel arch inner	14B1917	44	1	1			AHH5714	Com. (C) 6136		
17	Screw—clip to wheel arch inner	PMZ0310	45	1	1						
18	Washer for screw (plain)	PWZ103	46	1	1						
19	Washer for screw (spring)	LWZ203	47	1	1						
20	Nut for screw.....	FNZ103	48	1	1						
21	Hose—heater to blower	14A4762	49	1	1						
22	**Nozzle assembly—demister**	**14A1162**	**50**	**2**	**2**						
23	Screw—nozzle to scuttle	PTP603	51	4	4						
24	**Elbow—demister**	**14G3499**	**52**	**2**	**2**						
25	Clip—demister hose	27H168	53	2	2						
26	Hose—demister	14A4766	54	2	2						

Item No.	DESCRIPTION	Commencing (C) 501 Part Number	Illus. No.	Qty. per Vehicle RHD	Qty. per Vehicle LHD	Unit of Issue	Type of Vehicle	MODIFICATIONS New Part Number	MODIFICATIONS Change Point	MODIFICATIONS PAU No.	REMARKS
	FRESH AIR UNIT										
	(Optional Extra)										
1	**Fresh-air unit kit**	**8G9024**		**1 set**	**1 set**	1					
2	**Fresh-air unit assembly**	**13H56**		**1**	**1**						
3	Cover—side	17H1604	55	1	1						
4	Plate—valve flap	17H1606	56	1	1						
5	Lever arm and spindle	17H1609	57	1	1						
6	Grommet for seal	17H1607	58	1	1						
7	Clip	17H1605	59	4	4						
8	Washer	17H1608	60	2	2						
9	Seal—base	4B9713	61	1	1						
10	Screw—fresh-air unit to platform	PMZ0408	62	4	4	12					
11	Washer for screw (plain)	PWZ104	63	4	4						
12	Washer for screw (spring)	LWZ204	64	4	4						
13	**Control assembly—push-pull**	**13H57**	**65**	**1**	**1**						
14	Knob	17H1612	66	1	1						
15	Spindle	17H1610	67	1	1						
16	Screw	17H1611	68	1	1						
17	Trunnion	AHH5439	69	1	1						
18	Screw for trunnion	AHH5593	70	1	1						
19	Trunnion—control cable	14G6451		1	1						
20	Screw for trunnion	AHH5593		1	1						
21	**Plate—inlet flange**	**14A4763**	**71**	**1**	**1**						
22	Screw—plate to radiator and wheel arch bracket	PMZ0408		1	1						
23	Washer for screw (plain)	PWZ104		1	1	12					
24	Nut for screw	FNZ104		1	1						
25	**Hose—fresh-air unit to inlet flange**	**13H58**	**72**	**1**	**1**						
26	Clip—hose to fresh-air unit and inlet flange	14G800	73	2	2						
27	Clip—hose to wheel arch inner	14B1917	74	1	1			AHH5714	Com. (C) 6136		
28	Screw—clip to wheel arch inner	PMZ0310	75	1	1						
29	Washer for screw (plain)	PWZ103	76	1	1						
30	Washer for screw (spring)	LWZ203	77	1	1						
31	Nut for screw	FNZ103	78	1	1						



To face page S.7




To face page S.8

WINDSCREEN WASHER


(Optional Extra)

Item No.	DESCRIPTION	Commencing (C) 501 Part Number	Illus. No.	Qty. per Vehicle RHD	Qty. per Vehicle LHD	Unit of Issue	Type of Vehicle	MODIFICATIONS New Part Number	MODIFICATIONS Change Point	MODIFICATIONS PAU No.	REMARKS
1	**Screen washer kit (Trafalgar type)**	**N.S.P.**		**1 set**	**1 set**	1					**Single-jet mounting**
2	Container	17H579	1	1	1						
3	Cap and tube assembly	27H9662	2	1	1						
4	Bracket—container	14A5530	3	1	1						
5	Pump assembly	17H577	4	1	1						
6	Tube—suction	14A5531	5	1	1						
7	Tube—delivery	14A5532	6	1	1						
8	**Jet assembly—delivery**	**17H578**	**7**	**1**	**1**						
9	**Screen washer kit (Tudor type)**	**AHA5220**		**1 set**	**1 set**	1			Fin. (C) 26723		Not available use AHA5501
10	Container (small neck)	37H9763	8	1	1			**AHA5501**	**Com. (C) 26724**		**Twin-jet mountings**
11	Cap assembly (small)	7H9785	9	1	1				Fin. (C 26723		
12	Container (large neck)	37H9729		1	1						
13	Cap assembly (large)	37H9715		1	1			37H9716			
14	Bracket—container	27H9657	10	1	1						
15	**Mounting assembly—jet**	**27H9622**	**11**	**2**	**2**						
16	Jet	27H9623	12	2	2						
17	**Control assembly**	**27H9654**	**13**	**1**	**1**			**37H9730**	**Com. (C) 26724**		
18	Knob	27H9625	14	1	1						
19	Bulb (rubber)	27H9626	15	1	1			27H9824	Com. (C) 26724		
20	Washer (shakeproof)	7H9782	16	1	1						
21	Nut	27H9655	17	2	2						
22	Tubing (for use with Tudor type screen washer)	37H9708		A/R	A/R	50′ Roll					
23	Clip—water supply pipe	PCR0309	18	1	1						
24	Clip—water supply pipe	PCR0307	19	2	2						
25	Screw—clip to front wheel arch	PMZ0306	20	2	2						
26	Washer for screw (spring)	LWZ203	21	2	2						
27	Nut for screw	FNZ103	22	2	2						
28	Screw—container bracket to wheel arch	HZS0408	23	1	1						
29	Nut for screw	FNZ104	24	1	1						
30	Screw—container bracket to wheel arch and radiator support	HZS0404	25	1	1						
31	Washer for screw (spring)	LWZ204	26	1	1						
32	Nut for screw	FNZ104	27	1	1						

Item No.	DESCRIPTION	Commencing (C) 501 Part Number	Illus. No.	Qty. per Vehicle RHD	Qty. per Vehicle LHD	Unit of Issue	Type of Vehicle	MODIFICATIONS New Part Number	MODIFICATIONS Change Point	MODIFICATIONS PAU No.	REMARKS
	FRONT BUMPER										
	(Optional Extra)										
1	**Bumper assembly (front)**	**N.S.P.**		1	1						
2	Bar—spring	27H9607	28	1	1						
3	Spring (inner—R/H)	27H9608	29	1	1						
4	Spring (inner—L/H)	27H9609	30	1	1						
5	Spring (outer—R/H)	27H9610	31	1	1						
6	Spring (outer—L/H)	27H9611	32	1	1						
7	**Over-rider assembly**	**27H9612**	**33**	**2**	**2**						
8	Bolt—over-rider to bar	185373	34	2	2						
9	Washer for bolt (plain)	PWZ106	35	2	2						
10	Washer for bolt (spring)	LWZ306	36	2	2						
11	Nut for bolt	FNZ106	37	2	2						
12	Bolt—spring to bar	7H9740	38	2	2						
13	Washer for bolt (plain)	PWZ106	39	2	2						
14	Washer for bolt (spring)	LWZ306	40	2	2						
15	Nut for bolt	FNZ106	41	2	2						
16	Moulding (plastic)	27H9613	42	4	4						
17	Bolt—bumper to body	HBZ0612	43	4	4						
18	Washer for bolt (plain)	PWZ106	44	4	4						
19	Washer for bolt (spring)	LWZ206	45	4	4						
	NUMBER-PLATE AND SUPPORT										
20	**Plate—number (front) (Except N. AMERICA)**	**ADG474**	**46**	**1**	**1**						For use when front bumper is fitted
21	Screw—number-plate fixing	PMZ0412	47	2	2						
22	Washer—packing	AHH5712	48	6	6						
23	Washer for screw (spring)	LWZ204	49	2	2						
24	Nut for screw	FNZ104	50	2	2						
25	**Support—number-plate (N. AMERICA)**	**AHA5211**	**51**		**1**						
26	Screw—support fixing	PMZ0410	52		2						
27	Washer for screw (spring)	LWZ204	53		2						
28	Nut for screw	FNZ104	54		2						



To face page S.9



To face page S.10

Item No.	DESCRIPTION	Commencing (C) 501 Part Number	Illus. No.	Qty. per Vehicle RHD	Qty. per Vehicle LHD	Unit of Issue	Type of Vehicle	MODIFICATIONS New Part Number	MODIFICATIONS Change Point	MODIFICATIONS PAU No.	REMARKS
	TACHOMETER AND FITTINGS										
	(Optional Extra)										
1	**Tachometer**	**2A9068**		**1**	**1**						
2	Bezel	27H397	1	1	1						
3	Slip-ring	27H406	2	1	1						
4	Strap—fixing	27H429	3	1	1						
5	Ring (rubber)	AJH5178	4	1	1						
6	Glass	AJH5177	5	1	1						
7	Screw	17H1544	6	2	2						
8	Nut	17H1304	7	2	2						
9	Washer for screw	17H1341	8	2	2						
10	Bulb holder	3H914	9	2	2						
11	Bulb	2H4732	10	2	2						
12	**Cable—tachometer**	**2A9104**		**1**				**BHA4086**	]		
13	Cable (outer)	17H1497	11	1				17H1679	Com. (C) 3444		
14	Cable (inner)	17H1499	12	1				17H1678	]		
15	**Cable—tachometer**	**2A9108**			**1**						
16	Cable (outer)	17H1498			1						
17	Cable (inner)	17H1344			1						
18	Ratio box—cable to dynamo	2A9105	13	1	1						
19	Grommet—cable through dash	RFN305		1	1						
20	Bracket for cable	1K1977	14	1							
21	Grommet—cable through bracket	3H822	15	1							
22	Cable—tachometer illumination	2A9097		1	1						
	TONNEAU COVER										
	(Optional Extra)										
23	**Tonneau cover assembly (black)**	**AHA5256**	**16**	**1**							
24	Tonneau cover assembly (black)	AHA5257			1						
25	**Tonneau cover assembly (white)**			1	1			**AHA5482**	] **Com. (C) 13543**		
26	Tonneau cover assembly (white)				1			AHA5483	]		
27	Fastener—top portion	14B2465		4	4						
28	Eyelet	97H498		2	2						
29	Washer for eyelet	97H497		2	2						
30	Fastener	7H9961		3	3						
31	Stud	97H717		3	3						
32	Nut	AJD8012Z		3	3						
33	Washer (leather)	2K4936		3	3						

Item No.	DESCRIPTION	Commencing (C) 501 Part Number	Illus. No.	Qty. per Vehicle RHD	Qty. per Vehicle LHD	Unit of Issue	Type of Vehicle	MODIFICATIONS New Part Number	MODIFICATIONS Change Point	MODIFICATIONS PAU No.	REMARKS
	PAINTS—TOUCHING-UP—AIR DRYING										
1	**Cherry red**	**AKJ1016**		**1 pt.**	**1 pt.**					PAU/	
2	Cherry red	AKJ1017		1 qt.	1 qt.						
3	Cherry red	AKJ1018		½ gall.	½ gall.						
4	Cherry red	AKJ1019		1 gall.	1 gall.						
5	Cherry red	AKJ1020		5 gall.	5 gall.						
6	**Old English white**	AKJ1261		**1 pt.**	**1 pt.**						
7	Old English white	AKJ1262		1 qt.	1 qt.						
8	Old English white	AKJ1263		½ gall.	½ gall.						
9	Old English white	AKJ1264		1 gall.	1 gall.						
10	Old English white	AKJ1265		5 gall.	5 gall.						
11	**Speedwell blue**	**AKJ1**		**1 pt.**	**1 pt.**						
12	Speedwell blue	AKJ2		1 qt.	1 qt.						
13	Speedwell blue	AKJ3		½ gall.	½ gall.				Fin. (C) 9419		
14	Speedwell blue	AKJ4		1 gall.	1 gall.						
15	Speedwell blue	AKJ5		5 gall.	5 gall.						
16	**Primrose**	**AKJ1511**		**1 pt.**	**1 pt.**						
17	Primrose	AKJ1512		1 qt.	1 qt.						
18	Primrose	AKJ1513		½ gall.	½ gall.				Fin. (C) 9604		
19	Primrose	AKJ1514		1 gall.	1 gall.						
20	Primrose	AKJ1515		5 gall.	5 gall.						
21	**Dark Green**	**AKJ806**		**1 pt.**	**1 pt.**						
22	Dark green	AKJ807		1 qt.	1 qt.						
23	Dark green	AKJ808		½ gall.	½ gall.				Fin. (C) 9926		
24	Dark green	AKJ809		1 gall.	1 gall.						
25	Dark green	AKJ810		5 gall.	5 gall.						
26	**Leaf green**			**1 pt.**	**1 pt.**			**AKJ821**			
27	Leaf green			1 qt.	1 qt.			AKJ822			
28	Leaf green			½ gall.	½ gall.			AKJ823	Com. (C) 9927		
29	Leaf green			1 gall.	1 gall.			AKJ824			
30	Leaf green			5 gall.	5 gall.			AKJ825			
31	**Whitehall Nevada beige**			**1 pt.**	**1 pt.**			**AKJ516**			
32	Whitehall Nevada beige			1 qt.	1 qt.			AKJ517			
33	Whitehall Nevada beige			½ gall.	½ gall.			AKJ518	Com. (C) 9605		
34	Whitehall Nevada beige			1 gall.	1 gall.			AKJ519			
35	Whitehall Nevada beige			5 gall	5 gall.			AKJ520			
36	**Iris blue**			**1 pt.**	**1 pt.**			**AKJ56**			
37	Iris blue			1 qt.	1 qt.			AKJ57			
38	Iris blue			½ gall.	½ gall.			AKJ58	Com. (C) 9420		
39	Iris blue			1 gall.	1 gall.			AKJ59			
40	Iris blue			5 gall.	5 gall.			AKJ60			
41	**Thinners**	**AKJ2333**		**1 pt.**	**1 pt.**						**Correction, was AKJ2001**
42	Thinners	AKJ2334		1 qt.	1 qt.						Correction, was AKJ2002
43	Thinners	AKJ2335		½ gall.	½ gall.						Correction, was AKJ2003
44	Thinners	AKJ2336		1 gall.	1 gall.						Correction, was AKJ2004
45	Thinners	AKJ2337		5 gall.	5 gall.						Correction, was AKJ2005

PRINTED IN ENGLAND BY
THE NUFFIELD PRESS LIMITED
COWLEY, OXFORD
27/4 (29841) 7/60—7,280