SPRITE MK 3 AND MK 4, MIDGET MK 2 AND MK 3
PAGE INDEX

VEHICLE IDENTIFICATION DATA

IDENTIFICATION DATA . . . . . A 6
IDENTIFICATION CODES . . . . . A 7
KEY BLANK CHART . . . . . A 3
KEY TO BODY AND TRIM COLOURS . . . . . A 11
LIST OF ABBREVIATIONS . . . . . A 2
LOCATION OF UNIT NUMBERS . A 9

ENGINE AND CLUTCH

ENGINE UNIT–1098cc, 10CC . . . . . B 2
BEARING–CONNECTING ROD . B 6
BEARING–MAIN . . . . . B 6
BELT–FAN . . . . . B 22
BLADE–FAN . . . . . B 22
BLOCK ASSEMBLY–CYLINDER–HC . . . . . B 2
CAMSHAFT ASSEMBLY (WITH DRIVING PIN FOR OIL PUMP) . . B 6
CAP ASSEMBLY–OIL FILTER . B 14
CHAIN–GEAR . . . . . B 6
CLOSED-CIRCUIT BREATHING B 24
CONNECTING ROD ASSEMBLY–NOS. 1 AND 3 CYLINDERS . . . . B 6
CONNECTION–BY-PASS (RUBBER) . . . . . B 14
COVER–CYLINDER–FRONT–(WITH TIMING POINTER) . . . . B 16
COVER–CYLINDER–SIDE–REAR . . . . . B 16
COVER ASSEMBLY–VALVE ROCKER . . . . . B 14
CRANKSHAFT ASSEMBLY (WITH BUSH) . . . . . B 6
ELBOW–WATER OUTLET . . . . B 14
ELEMENT–OIL FILTER . . . . . B 20
ENGINE UNIT–STRIPPED–HC . . B 2
ENGINE UNIT–HALF–HC . . . . . B 2
FAN–DYNAMO . . . . . B 22
FILTER ASSEMBLY–OIL . . . . . B 20
FLYWHEEL ASSEMBLY . . . . . B 8
GASKET–CYLINDER HEAD . . B 12
GASKET–ROCKER COVER TO CYLINDER HEAD . . . . . B 14
GASKET–SUMP TO CRANKCASE . . . . . B 18
GEAR–CRANKSHAFT . . . . . B 6
GEAR ASSEMBLY–CAMSHAFT (WITH TENSIONER RINGS) . . . . B 6
GUIDE–VALVE . . . . . B 10
HEAD ASSEMBLY–CYLINDER (WITH VALVES) . . . . . B 10
HEAD ASSEMBLY–CYLINDER B 10
HOUSING–DISTRIBUTOR . . . . . B 8
KIT–WATER PUMP REPAIR . . . B 22
LINER–CYLINDER . . . . . B 2
LINK–DYNAMO ADJUSTING . . B 22
MANIFOLD ASSEMBLY–INLET B 24
MANIFOLD–EXHAUST . . . . . B 24
PISTON ASSEMBLY–ENGINE SET–GRADE 3–HC . . . . . B 4
PLATE–ENGINE MOUNTING–FRONT . . . . . B 8
PLATE–ENGINE MOUNTING . . B 16
PLUG–SPARKING . . . . . B 14
PULLEY–CRANKSHAFT . . . . . B 8
PULLEY–DYNAMO . . . . . B 22
PULLEY–WATER PUMP . . . . . B 22
PUMP (CONCENTRIC) . . . . . B 18
PUMP ASSEMBLY–OIL–(HOBOURN) . . . . . B 18
PUMP ASSEMBLY–WATER . . . B 22
PUSH–ROD . . . . . B 8
RING–PISTON–ENGINE SET . . . B 4
ROCKER ASSEMBLY . . . . . B 12
ROD–DIPPER . . . . . B 18
SCREW–TAPPET ADJUSTING . B 12
SEAL–OIL–TIMING COVER . . B 16
SHAFT ASSEMBLY–VALVE ROCKER . . . . . B 12
SPINDLE–DISTRIBUTOR DRIVE . . . . . B 8
SUMP . . . . . B 18
TAP–CYLINDER DRAIN . . . . . B 2
TAPPET . . . . . B 8
THERMOSTAT–WAX TYPE . . . B 14
VALVE–EXHAUST . . . . . B 10
VALVE–INLET . . . . . B 10
VALVE–OIL RELEASE . . . . . B 18
VALVE ASSEMBLY–BREATHER CONTROL . . . . . B 24
ENGINE UNIT–1275cc, 12CC, 12CD, 12CE, 12CJ AND 12V . . . . . B 26
BEARING–CONNECTING ROD–STANDARD . . . . . B 28
BEARING–MAIN–STANDARD . B 28
BELT–FAN . . . . . B 56
BLOCK ASSEMBLY–CYLINDER–HC . . . . . B 26
CAMSHAFT . . . . . B 30,
CAP ASSEMBLY–OIL FILLER . B 40
CARTRIDGE (DISPOSABLE)–OIL FILTER . . . . . B 50.02
CHAIN–TIMING . . . . . B 30
CONNECTION–BY-PASS ADAPTOR . . . . . B 42
COVER–FRONT–TIMING (WITH OIL SEPARATOR) . . . . . B 44
COVER ASSEMBLY–VALVE ROCKER . . . . . B 40
CRANKSHAFT ASSEMBLY . . . B 28
ELBOW–WATER OUTLET . . . . B 42
ELEMENT (FELT) . . . . . B 50
ENGINE UNIT–STRIPPED–HC . B 26
ENGINE UNIT–PART–HC . . . . B 26
FAN–6 BLADE (PLASTIC) . . . . B 56
FAN–DYNAMO . . . . . B 56
FILTER ASSEMBLY–OIL (PUROLATOR) . . . . . B 50
FLANGE–DRIVING–OIL PUMP B 30
FLYWHEEL ASSEMBLY . . . . . B 30
GASKET–CYLINDER HEAD . . B 38
GASKET–ROCKER COVER . . . B 40
GASKET–SUMP TO CRANKCASE . . . . . B 48
GEAR–CAMSHAFT . . . . . B 30
GEAR–CRANKSHAFT . . . . . B 28
GEAR–RING–STARTER . . . . . B 30
GUIDE–INLET AND EXHAUST B 34
HEAD ASSEMBLY–CYLINDER (WITH GUIDES, PLUGS AND STUDS) . . . . . B 34
HOUSING–DISTRIBUTOR . . . . B 32
KIT–REPAIR–WATER PUMP . . B 52
LINER–CYLINDER BLOCK . . . B 26
LINK–DYNAMO ADJUSTING . . B 56
PISTON ASSEMBLY–ENGINE SET–GRADE 3–HC . . . . . B 26.02
PLATE–ENGINE MOUNTING–FRONT . . . . . B 30
PLATE–GEARBOX MOUNTING B 44
PLUG–DRAIN . . . . . B 48
PLUG ASSEMBLY–SPARKING . B 42
PULLEY–DYNAMO . . . . . B 56
PULLEY–FAN AND WATER PUMP . . . . . B 54
PUMP ASSEMBLY–OIL . . . . . B 46
PUMP ASSEMBLY–WATER . . . B 52
PUSH-ROD . . . . . B 32
RING–PISTON–ENGINE SET B 26.02
ROCKER ASSEMBLY–VALVE . B 38
ROD ASSEMBLY–CONNECTING . . . . . B 28
ROD ASSEMBLY–OIL DIPPER . B 48
SCREW–TAPPET ADJUSTING . B 38
SHAFT ASSEMBLY–ROCKER . B 38
SPINDLE–DISTRIBUTOR DRIVE B 32
SPRING–VALVE–INNER . . . . B 36
SUMP–OIL . . . . . B 48
TAP–CYLINDER DRAIN . . . . . B 26
TAPPET . . . . . B 32
THERMOSTAT (WAX TYPE) . . . B 42
TUBE–AIR INJECTOR . . . . . B 36
VALVE–EXHAUST . . . . . B 36
VALVE–INLET . . . . . B 36
VALVE–OIL RELEASE . . . . . B 46
ENGINE SERVICE KITS–1098cc–10CC . . . . . B 58
SET–GASKET–ENGINE DECARBONIZING . . . . . B 58
SET–GASKET–SUPPLEMENTARY . . . . . B 58
ENGINE SERVICE KITS–1275cc–12CC, 12CD, 12CE, 12CJ and 12V . . . . . B 60
ENGINE UNIT–MANIFOLDS–1275cc–12CC, 12CD, 12CE, 12CJ AND 12V . . . . . B 62
GASKET–MANIFOLD TO CYLINDER HEAD . . . . . B 62
MANIFOLD ASSEMBLY–INLET B 62
MANIFOLD–EXHAUST . . . . . B 62
ENGINE UNIT–CLOSED CIRCUIT BREATHING–1275cc–12CC, 12CD, 12CE, 12CJ AND 12V . . . . . B 64
CLOSED-CIRCUIT BREATHING (VENTED THROUGH INLET MANIFOLD) . . . . . B 64
CLOSED-CIRCUIT BREATHING (VENTED THROUGH CARBURETTERS) . . . . . B 64
VALVE ASSEMBLY–BREATHER CONTROL . . . . . B 64
ENGINE UNIT–EXHAUST EMISSION CONTROL–1275cc–12CD, 12CJ, 12V . . . . . B 66

SPRITE MK 3 AND MK 4, MIDGET MK 2 AND MK 3
PAGE INDEX

Item	Page No.
CLEANER ASSEMBLY–AIR (PLASTIC) $	B 66
LINK–ADJUSTING–AIR PUMP $	B 68
MANIFOLD–AIR $	B 66
VALVE–GULP $	B 68
OIL COOLER–OPTIONAL EXTRA–ALL VERSIONS–EXCEPT 1500	B 70
ADAPTOR–UNION–OIL–FILTER	B 72
ADAPTOR–UNION–CYLINDER BLOCK	B 72
COOLER–OIL	B 70
CLUTCH–ALL VERSIONS	B 74
BEARING–RELEASE	B 74
PLATE–PRESSURE	B 74
PLATE ASSEMBLY–DRIVEN	B 74
ENGINE MOUNTINGS–ALL VERSIONS–EXCEPT 1500	B 76
BRACKET–FRONT MOUNTING	B 76
MOUNTING–FRONT	B 76
MOUNTING–REAR	B 76
STRAP–GEARBOX STEADY	B 76
TUBE–ENGINE RESTRAINT	B 76
ENGINE UNIT–1500	B 78
BEARING–CONNECTING ROD ENGINE SET	B 80
BEARING–MAIN–ENGINE SET	B 80
CAMSHAFT	B 82
CAP–OIL–FILLER	B 90
CHAIN–TIMING	B 82
COUPLING–FAN DRIVE	B 92
COVER–TIMING	B 84
CRANKSHAFT	B 80
ELBOW–WATER OUTLET	B 92
ENGINE GASKET SETS	B 94
ENGINE UNIT–SHORT	B 78
FAN	B 92
FAN-BELT	B 92
FILTER–OIL	B 86
FLYWHEEL	B 84
GASKET–CYLINDER HEAD	B 88
GASKET–MANIFOLD TO HEAD	B 94
GEAR–CAMSHAFT	B 82
GEAR–CRANKSHAFT	B 82
GEAR–DISTRIBUTOR AND OIL PUMP DRIVE	B 82
GEAR–STARTER RING	B 84
HEAD ASSEMBLY–CYLINDER	B 88
HOUSING–OIL SEAL–REAR	B 78
LINER–CYLINDER BLOCK	B 86
MANIFOLD–INLET	B 94
MANIFOLD–EXHAUST	B 94
PEDESTAL–DISTRIBUTOR	B 82
PIPE–WATER PUMP TO INLET MANIFOLD–REAR	B 94
PISTON ASSEMBLY–ENGINE SET (9.0 : 1 COMPRESSION RATIO)	B 80
PISTON ASSEMBLY–ENGINE SET (7.5 : 1 COMPRESSION RATIO)	B 80
PLATE–ENGINE–FRONT	B 86
PLATE–GEARBOX MOUNTING	B 86
PLUG–CYLINDER DRAIN	B 86
PLUG–SUMP–DRAIN	B 86
PRE-HEATER	B 94
PULLEY–CRANKSHAFT	B 84
PUMP AND STRAINER–OIL	B 86
PUSH-ROD	B 88
RING–PISTON–ENGINE SET	B 80
ROD–CONNECTING	B 80
ROD–OIL DIPPER	B 86
SCREW–ROCKER ADJUSTING	B 90
SEAL–OIL–TIMING COVER	B 84
SET–GASKET–DECARBONIZING	B 94
SET–GASKET–SUPPLEMENTARY	B 94
SHAFT–OIL PUMP DRIVE	B 82
SHAFT–ROCKER	B 90
SPRING–VALVE–OUTER	B 88
SUMP–OIL	B 86
TAPPET	B 88
TENSIONER	B 82
THERMOSTAT 82C	B 92
TUBE–OIL–DIPPER ROD	B 80
VALVE–EXHAUST	B 88
VALVE–INLET	B 88
WATER PUMP ASSEMBLY	B 92
ENGINE UNIT 1500–USA–CANADA 1977 ON	B 94.02
ENGINE UNIT–1500–EMISSION CONTROL–1974	B 96
CANISTER–CARBON	B 96
VALVE–ANTI-RUN-ON	B 96
ENGINE UNIT–1500 EMISSION BREATHER–1975 TO 1977	B 96.02
CANNISTER–CARBON	B 96.02
FUEL TRAP	B 96.02
VALVE–ANTI-RUN-ON	B 96.02
ENGINE UNIT–1500–EMISSION BREATHER–1977 ON	B 96.04
AIR PUMP AND MANIFOLD–MIDGET 1500 TO 1977	B 98
BELT–DRIVE–AIR PUMP	B 98
CLEANER–AIR–AIR PUMP	B 98
MANIFOLD–AIR INJECTION	B 98
PULLEY–AIR PUMP	B 98
TUBE–AIR INJECTION	B 98
VALVE–NON-RETURN	B 98
AIR PUMP AND INJECTION PIPE–MIDGET–1500 1977 ON	B 98.02
ENGINE MOUNTINGS–MIDGET 1500	B 102
CABLE–ENGINE RESTRAINT	B 102
RUBBER–ENGINE RESTRAINT	B 102
GEARBOX/TRANSMISSION	
GEARBOX–1098cc AND 1275cc	C 2
1ST SPEED WHEEL–2ND SPEED SYNCHRONIZER ASSEMBLY	C 6
CASE ASSEMBLY	C 2
EXTENSION ASSEMBLY–GEARBOX (WITH BUSH AND SEAL)	C 8
GAITER–GEAR LEVER	C 12
GASKET–EXTENSION TO GEARBOX	C 10
GEAR–2ND SPEED	C 6
GEAR–3RD SPEED	C 6
GEARBOX ASSEMBLY	C 2
LAYGEAR	C 4
LAYSHAFT	C 4
LEVER–CHANGE SPEED	C 12
PINION–SPEEDOMETER	C 8
RING–BAULK	C 4
SHAFT–1ST MOTION	C 4
SHAFT–3RD MOTION	C 4
SHAFT–REMOTE CONTROL	C 8
SWITCH ASSEMBLY–REVERSE LIGHT	C 12
SYNCHRONIZER ASSEMBLY–3RD AND 4TH SPEED	C 4
WHEEL–SPEEDOMETER	C 6
WHEEL ASSEMBLY–REVERSE	C 6
1500cc–GEARBOX ASSEMBLY–CLUTCH HOUSING AND LEVER–SELECTOR MECHANISM	C 14
BEARING–BALL–REAR	C 18
CASE–GEARBOX	C 20
CYLINDER–CLUTCH OPERATING	C 14
FLANGE	C 18
FORK–1ST AND 2ND SPEED	C 20
FORK–3RD AND 4TH SPEED	C 20
GEAR–1ST SPEED	C 16
GEAR–2ND SPEED	C 16
GEAR–3RD SPEED	C 18
GEAR–REVERSE–IDLER	C 18
GEARBOX ASSEMBLY	C 16
HOUSING–CLUTCH	C 14
LAYGEAR	C 18
LAYSHAFT	C 18
LEVER–CHANGE SPEED	C 22
LEVER–CLUTCH OPERATING	C 14
LEVER–REVERSE OPERATING	C 20
MAINSHAFT	C 16
PINION–SPEEDOMETER (22 TEETH)	C 22
PLATE–CLUTCH DRIVEN	C 14
PLUG–OIL FILLER AND DRAIN	C 20
SEAL–OIL–GEARBOX REAR EXTENSION	C 18
SHAFT–1ST MOTION	C 16
SHAFT–GEAR SELECTOR	C 20
SHAFT–SELECTOR FORKS	C 20
SPOOL–INTERLOCK	C 20
SWITCH–INHIBITOR (SEAT BELT)	C 22
SWITCH–REVERSE LIGHT	C 22
SYNCHRONIZER ASSEMBLY–1ST AND 2ND SPEED	C 16
SYNCHRONIZER ASSEMBLY–3RD AND 4TH SPEED	C 18
WHEEL–SPEEDOMETER (6 TEETH)	C 18
COOLING, FUEL, EXHAUST SYSTEMS	
RADIATOR–VERTICAL FLOW AND FITTINGS	D 2
CAP–FILLER	D 2
HOSE–RADIATOR TO WATER PUMP	D 2
HOSE–RADIATOR TO OUTLET HOSE	D 2

SPRITE MK 3 AND MK 4, MIDGET MK 2 AND MK 3
PAGE INDEX

Item	Page No.
RADIATOR–CROSS-FLOW AND FITTINGS–EXCEPT 1500	D 4
CAP–FILLER	D 4
HOSE–RADIATOR TO WATER PUMP	D 4
HOSE–RADIATOR TOP	D 4
TANK–EXPANSION	D 4
RADIATOR–CROSS-FLOW AND FITTINGS–1500	D 4.02
CAP–FILLER	D 4.02
HOSE–RADIATOR–TOP	D 4.02
HOSE–RADIATOR–LOWER	D 4.02
SWITCH–THERMO–VAC	D 4.02
TANK–EXPANSION	D 4.02
FUEL TANK AND FITTINGS–NOT EVAPORATIVE LOSS CONTROL	D 6
CAP ASSEMBLY–FILLER $	D 6
UNIT–FUEL GAUGE	D 6
FUEL TANK AND FITTINGS–EVAPORATIVE LOSS CONTROL EQUIPMENT	D 8
CANISTER ASSEMBLY–CARBON	D 10
CAP–FILLER $	D 8
PIPE–FUEL (FLEXIBLE)	D 10
PUMP–FUEL	D 10
TANK–VAPOUR SEPARATING $	D 8
UNIT–FUEL GAUGE	D 8
FUEL PIPES AND FITTINGS	D 12
MOUNTING–FUEL PUMP (RUBBER)	D 12
FUEL PUMP–EXCEPT MIDGET 1500	D 14
FUEL PUMP–RAC HOMOLOGATED	D 16
FUEL PUMP AND FIXINGS–MIDGET 1500	D 16.02
CARBURETTER INSTALLATION–NON-VENTILATED TYPE–NOT USA AND CANADA	D 18
CARBURETTER INSTALLATION	D 18
CARBURETTER ASSEMBLY–FRONT	D 20
CARBURETTER ASSEMBLY–REAR	D 22
CARBURETTER INSTALLATION–VENTILATED TYPE–NOT USA AND CANADA	D 24
CARBURETTER INSTALLATION	D 24
CARBURETTER ASSEMBLY–FRONT	D 26
CARBURETTER ASSEMBLY–REAR	D 28
FRONT CARBURETTER FOR 12V/778F ENGINES ONLY	D 28.02
REAR CARBURETTER FOR 12V/778F ENGINES ONLY	D 28.04
CARBURETTER INSTALLATION–NON-VENTILATED TYPE–USA AND CANADA	D 30
CARBURETTER INSTALLATION	D 30
CARBURETTER ASSEMBLY–FRONT	D 32
CARBURETTER ASSEMBLY–REAR	D 34
CARBURETTER INSTALLATION–VENTILATED TYPE–USA AND CANADA	D 36
CARBURETTER INSTALLATION	D 36
CARBURETTER ASSEMBLY–FRONT	D 38
CARBURETTER ASSEMBLY–REAR	D 44
CARBURETTER INSTALLATION–MIDGET 1500, NOT USA AND CANADA	D 48.04
CARBURETTER ASSEMBLY–FRONT	D 48.04
CARBURETTER ASSEMBLY–REAR	D 48.08
CARBURETTER ASSEMBLY–MIDGET 1500–USA AND CANADA	D 48.12
CARBURETTER ASSEMBLY	D 48.12
KIT–CARBURETTER	D 48.12
CARBURETTER FITTINGS–HEAT SHIELD–AIR CLEANER–EXCEPT MIDGET 1500	D 50
CLEANER ASSEMBLY–AIR–FRONT	D 50
ELEMENT–AIR CLEANER	D 50
SHIELD–HEAT	D 50
SPRING–THROTTLE RETURN	D 50
AIR CLEANER AND SILENCER–MIDGET 1500	D 50.02
COMPENSATOR–AIR TEMPERATURE	D 50.02
ELEMENT–AIR CLEANER	D 50.02
CARBURETTER FITTINGS–HEAD SHIELD–MIDGET 1500–NOT USA AND CANADA	D 50.04
CARBURETTER FITTINGS–MIDGET 1500–USA AND CANADA	D 50.06
EXHAUST SYSTEM–EXCEPT 1500	D 52
CLAMP–PIPE TO MANIFOLD	D 52
DOWN PIPE	D 56
EXHAUST SYSTEM COMPLETE	D 52
EXHAUST SYSTEM COMPLETE (C$)	D 56
JOINT–EXHAUST DOWN-PIPE $ (C$)	D 52
MOUNTING–PIPE $	D 52
MOUNTING–PIPE–LH	D 54
MOUNTING–PIPE–LH	D 58
PIPE–EXHAUST	D 52
SILENCER	D 54
STEERING, F/AXLE, SUSPENSION	
STEERING RACK	E 2
PINION–RHD	E 4
RACK ASSEMBLY–RHD	E 2
RACK ASSEMBLY–RHD $	E 10
SEAL–PINION	E 6
SOCKET ASSEMBLY–BALL–OUTER $	E 8
TIE-ROD ASSEMBLY $	E 8
STEERING COLUMN AND LOCK–EXCEPT N. AMERICA	E 12
COLUMN–INNER–RHD AND LHD	E 12
COLUMN–OUTER	E 12
HORN PUSH–MIDGET	E 16
HORN PUSH–SPRITE	E 16
LOCK ASSEMBLY (WITH IGNITION SWITCH)	E 12
WHEEL–STEERING	E 14
STEEERING COLUMN–COLLAPSIBLE TYPE–AND STEERING LOCKS–N. AMERICA	E 18
COLUMN–STEERING $	E 18
HORN PUSH	E 18
KIT–STEERING LOCK	E 20
LOCK ASSEMBLY (WITH IGNITION SWITCH)–USA FOR GERMANY $	E 20
WHEEL–STEERING $	E 18
FRONT SUSPENSION	E 22
BEARING–HUB–OUTER $	E 24
BEARING–HUB–INNER $	E 24
HUB ASSEMBLY $	E 24
KIT–REPAIR–SWIVEL PIN AND BUSH $	E 22
LEVER–STEERING–RH $	E 24
LINK ASSEMBLY–LOWER $	E 22
PIN–FULCRUM $	E 22
SEAL–OIL $	E 24
STUD–WHEEL $	E 24
TRUNNION–SUSPENSION LINK $	E 22
FRONT SHOCK ABSORBERS	E 26
ABSORBER–SHOCK–RH $	E 26
BUFFER REBOUND	E 26
BUFFER SUSPENSION	E 26
PIN–FULCRUM–SHOCK ABSORBER TO TRUNNION $	E 26
PIN–FULCRUM–LOWER LINK TO FRAME $	E 26
SPRING–ROAD COIL	E 26
FRONT BRAKES	E 28
DISC–BRAKE $	E 28
PAD ASSEMBLY	E 28
UNIT ASSEMBLY–CALLIPER –LH	E 28
ANTI-ROLL BAR	E 30
PROP SHAFT, R/AXLE, SUSPENSION	
PROPELLER SHAFT	F 2
REAR AXLE	F 4
BEARING–DIFFERENTIAL	F 4
BEARING–INNER–PINION	F 6
BEARING–OUTER–PINION	F 6
CASE ASSEMBLY	F 4
CROWN WHEEL AND PINION–9 x 38 TEETH (4.22 : 1 RATIO)	F 6
CROWN WHEEL AND PINION–10 x 39 TEETH (3.90 : 1 RATIO)	F 6
DIFFERENTIAL ASSEMBLY–9 x 38 TEETH (4.22 : 1 RATIO)	F 4
DIFFERENTIAL ASSEMBLY–10 x 39 TEETH (3.90 : 1 RATIO)	F 4
HUB ASSEMBLY $	F 6
PINION–DIFFERENTIAL	F 4
SEAL–OIL	F 6
SHAFT–AXLE	F 6

SPRITE MK 3 AND MK 4, MIDGET MK 2 AND MK 3
PAGE INDEX

Item	Page No.
WHEEL–DIFFERENTIAL	F 4
REAR BRAKES	F 8
CYLINDER ASSEMBLY–WHEEL $	F 8
DRUM–BRAKE $	F 8
KIT–REPAIR–WHEEL CYLINDER $	F 8
SHOE ASSEMBLY–BRAKE $	F 8
REAR SPRINGS	F 10
LEAF ASSEMBLY–MAIN	F 10
LEAF ASSEMBLY–MAIN	F 10
SPRING ASSEMBLY	F 10
REAR SPRING FIXINGS	F 12
BRACKET–SPRING	F 12
BUSH–SHACKLE	F 12
MOUNTING–SPRING–FRONT $	F 12
PLATE–SHACKLE (WITH PIN) $	F 12
RUBBER–BUMP	F 12
STRAP–REBOUND	F 12
REAR SHOCK ABSORBERS	F 14
CONTROLS–ENGINE, CLUTCH, BRAKE	
ENGINE CONTROLS	G 2
CABLE–ACCELERATOR CONTROL $	G 2
CABLE–MIXTURE CONTROL	G 2
PEDAL–ACCELERATOR $	G 2
CLUTCH PEDAL AND LINKAGE	G 4
CLUTCH MASTER AND OPERATING CYLINDERS	G 6
CLUTCH OPERATING CYLINDER 1098cc (10CC)	G 6
CLUTCH OPERATING CYLINDER 1275cc (12CC, 12CD, 12CE, 12CJ, 12V)	G 8
CYLINDER AND SUPPLY TANK ASSEMBLY–CLUTCH MASTER	G 6
KIT–REPAIR–MASTER CYLINDER	G 6
CLUTCH PIPES	G 10
HOSE–OPERATING CYLINDER	G 12
PIPE–CLUTCH–4.762MM (0.1875") O/D	G 12
PIPE–CLUTCH–6.35MM (0.25") O/D	G 12
BRAKE PEDAL–SINGLE LINE SYSTEM	G 14
PAD–PEDAL (RUBBER)	G 14
PEDAL ASSEMBLY–BRAKE	G 14
SPRING–PEDAL RETURN $	G 14
BRAKE MASTER CYLINDER–SINGLE LINE SYSTEM	G 16
CYLINDER AND SUPPLY TANK BRAKE AND CLUTCH–MASTER	G 16
KIT–REPAIR–BRAKE MASTER CYLINDER	G 16
TANK–FLUID (PLASTIC)	G 16
BRAKE PIPES AND FITTINGS –SINGLE LINE BRAKING SYSTEM	G 18
HOSE–FRONT BRAKE $	G 18.02
HOSE–REAR BRAKE	G 18.02
PIPE–BRAKE 0.187" (4.762MM) O/D	G 18
SWITCH–STOP LIGHT	G 20
BRAKE PEDAL–DUAL LINE SYSTEM	G 22
PAD–PEDAL (RUBBER)	G 22
PEDAL ASSEMBLY–BRAKE	G 22
SPRING–PEDAL RETURN $	G 22
BRAKE MASTER CYLINDER–DUAL LINE SYSTEM	G 24
CYLINDER AND SUPPLY TANK ASSEMBLY–BRAKE MASTER (LESS PUSH-ROD) $	G 24
KIT–REPAIR–MASTER CYLINDER $	G 24
BRAKE PIPES AND FITTINGS–DUAL LINE BRAKING SYSTEM	G 26
HOSE–FRONT BRAKE	G 28
HOSE–REAR BRAKE	G 28
PIPE–BRAKE–0.187" (4.762MM) O/D	G 26
PIPE–BRAKE–0.187" (4.762MM) O/D	G 26.02
SWITCH–STOPLIGHT $	G 28
SWITCH ASSEMBLY–PRESSURE FAILURE $	G 28
HAND BRAKE LEVER AND LINKAGE	G 30
CABLE ASSEMBLY–HAND BRAKE $	G 30
HAND BRAKE ASSEMBLY $	G 30
ELECTRICAL AND INSTRUMENTS	
DISTRIBUTOR–10CC–1098cc	H 2
ARM–ROTOR	H 2
CONTACTS	H 2
COVER–WATERPROOF	H 2
VACUUM UNIT	H 2
DISTRIBUTOR–1275cc, 12CC, 12CD, 12CE, 12CJ AND 12V	H 4
ARM–ROTOR	H 4
BODY–SUPPRESSION SCREEN	H 6
CONTACTS	H 4
COVER–WATERPROOF	H 4
COVER ASSEMBLY–MOULDED	H 4
DISTRIBUTOR ASSEMBLY	H 4
SEAL (RUBBER)–DISTRIBUTOR	H 6
DISTRIBUTOR–MIDGET 1500–NOT USA	H 6.02
ARM–ROTOR	H 6.02
CONDENSER (WITH LEAD)	H 6.02
CONTACT SET	H 6.02
VACUUM UNIT	H 6.02
DISTRIBUTOR–MIDGET 1500 – USA AND CANADA	H 6.04
MODULE–ELECTRONIC	H 6.04
IGNITION COIL LEAD KIT AND VACUUM PIPE–MIDGET 1500	H 6.06
VACUUM CONTROL PIPE–IGNITION COIL–NOT 1500	H 8
COIL–IGNITION	H 8
COVER–WATERPROOF	H 8
PIPE ASSEMBLY–VACUUM CONTROL	H 8
IGNITION CABLES–1098cc	H 10
CABLE–IGNITION	H 10
CONNECTOR ASSEMBLY–SPARKING PLUG	H 10
IGNITION CABLES–1275cc–POSITIVE EARTH ELECTRICAL SYSTEM	H 12
CABLE–IGNITION–COMPLETE	H 12
CAP–SPARKING PLUG	H 12
IGNITION CABLES–1275cc–NEGATIVE EARTH ELECTRICAL SYSTEM–12CD, 12CE, 12CJ AND 12 V	H 14
CABLE–IGNITION	H 14
DYNAMO–POSITIVE EARTH ELECTRICAL SYSTEM	H 16
DYNAMO ASSEMBLY (22742)	H 16
DYNAMO ASSEMBLY (22700 A TO M)	H 16
DYNAMO ASSEMBLY (22775)–12CD, 12CE	H 18
DYNAMO ASSEMBLY (22715)	H 18
ALTERNATOR AND FITTINGS–1275cc–12V–OPTIONAL EXTRA	H 20
LINK–ADJUSTING	H 20.02
PULLEY	H 20.02
ALTERNATOR AND FIXINGS–MIDGET 1500	H 20.04
ALTERNATOR ASSEMBLY–BATTERY SENSED–16ACR	H 20.04
BELT–FAN	H 20.04
FAN–ALTERNATOR	H 20.04
PULLEY–ALTERNATOR	H 20.04
STARTER–EXCEPT MIDGET 1500	H 22
RELAY–STARTER MOTOR SOLENOID	H 22
STARTER ASSEMBLY (25079 A TO H)	H 22
STARTER ASSEMBLY–TYPE M35J (25149)	H 22
STARTER AND FIXINGS–MIDGET 1500	H 22.02
STARTER ASSEMBLY–TYPE M35J	H 22.02
BATTERY AND FIXINGS	H 24
WIRING CABLES AND FITTINGS CONNECTORS, AND BULB HOLDERS	H 26
BULB (BAYONET TYPE)	H 28
BULB (SCREW TYPE)	H 28
CABLE–BATTERY	H 32
CABLE–ENGINE TO EARTH	H 32
CABLE–STARTER SWITCH TO STARTER	H 32
CABLE ASSEMBLY–MAIN HARNESS	H 26
CABLE ASSEMBLY–MAIN HARNESS–N. AMERICA	H 26.02
CABLE ASSEMBLY–BODY HARNESS	H 30
CONNECTOR	H 28
FUSE–10AMP	H 30
HOLDER–FUSE	H 30
CONTROL BOX AND FUSE BOX	H 34
CONTROL BOX ASSEMBLY	H 34
FUSE (35 AMP)	H 34
FUSEBOX ASSEMBLY	H 34
RELAY–STARTER MOTOR SOLENOID	H 34

SPRITE MK 3 AND MK 4, MIDGET MK 2 AND MK 3
PAGE INDEX

Item	Page No.
SWITCHES–TOGGLE/ROCKER TYPE SYSTEM	H 36
BARREL–LOCK–IGNITION SWITCH	H 36.02
CIGAR–LIGHTER ASSEMBLY	H 36.02
SWITCH	H 36
SWITCH–COURTESY LIGHT–TRUNK	H 40
SWITCH–COURTESY LIGHT–INTERIOR	H 40
SWITCH–DIRECTION INDICATOR/HORN/HEADLAMP FLASHER	H 40
SWITCH–STARTER SOLENOID	H 36.02
SWITCH ASSEMBLY–IGNITION	H 36
SWITCH ASSEMBLY–DIRECTION INDICATOR	H 38
SWITCH ASSEMBLY–DIRECTION INDICATOR AND HEADLAMP FLASHER	H 38
UNIT–FLASHER	H 42
UNIT–FLASHER–HAZARD WARNING $	H 42
SWITCHES–(USA TYPES)	H 44
BARREL–LOCK–IGNITION SWITCH	H 50
BUZZER–IGNITION KEY WARNING	H 50
CIGAR LIGHTER ASSEMBLY	H 52
LAMP–HAZARD WARNING $	H 52
LIGHT–WARNING 'FASTEN BELTS'	H 52
SWITCH–COURTESY LIGHT–INTERIOR	H 50
SWITCH–IGNITION	H 50
SWITCH–IGNITION KEY AUDIBLE WARNING AND COURTESY LIGHT	H 50
SWITCH–STARTER SOLENOID	H 48
UNIT–CONTROL–SEQUENTIAL SEAT SYSTEM $	H 52
UNIT–FLASHER $	H 50
UNIT–HAZARD WARNING	H 52
HORN AND CONTROLS	H 54
HORN-PUSH ASSEMBLY–SPRITE	H 54
HORN-PUSH ASSEMBLY–MIDGET	H 54
HORN ASSEMBLY–HIGH NOTE	H 54
HEADLAMPS–RHD AND LHD FOR USA AND CANADA	H 56
HEADLAMPS–RHD AND LHD FOR USA AND CANADA–1500	H 56.02
HEADLAMPS–LHD EXCEPT EUROPE, USA, CANADA AND MIDGET 1500	H 58
HEADLAMPS–EUROPE EXCEPT FRANCE AND MIDGET 1500	H 60
HEADLAMPS–FRANCE EXCEPT MIDGET 1500	H 62
HEADLAMPS–WEST GERMANY EXCEPT MIDGET 1500	H 64
LAMP–SIDE AND FLASHER	H 66
LAMP ASSEMBLY FLASHER–AMBER	H 66
LAMP ASSEMBLY–SIDE AND FLASHER–WHITE	H 68
STOP/TAIL LAMPS	H 70
BULB–FLASHER	H 70
BULB–STOP/TAIL	H 70
LENS–FLASHER–AMBER	H 70
LENS–FLASHER–RED $	H 70
LENS–STOP/TAIL	H 70
LAMP–REVERSE	H 74
LAMP–REFLEX	H 76
NUMBER PLATE LAMPS AND FOGLAMP	H 78
COURTESY LIGHT ASSEMBLY–BOOT	H 78.02
COURTESY LIGHT ASSEMBLY–INTERIOR	H 78.02
LAMP ASSEMBLY–NUMBER PLATE	H 78
LAMP ASSEMBLY–FOG	H 78.02
WINDSCREEN WIPERS–2 BLADE SYSTEM	H 80
ARM–WIPER–RHD	H 80
BLADE–WIPER	H 80
MOTOR ASSEMBLY–WINDSCREEN WIPER	H 80
MOTOR ASSEMBLY–WINDSCREEN WIPER (LESS GEAR) A/B AND D	H 82
WHEELBOX ASSEMBLY	H 80
WINDSCREEN WIPERS–3 BLADE SYSTEM	H 86
SPEEDOMETER	H 88
STABILIZER–VOLTAGE	H 88
SPEEDOMETER CABLE	H 90
TACHOMETER	H 92
GAUGE–FUEL	H 94
GAUGE–OIL PRESSURE AND WATER TEMPERATURE	H 96
OIL PRESSURE GAUGE PIPES AND FITTINGS–EXCEPT MIDGET 1500	H 98
OIL PRESSURE GAUGE PIPES AND FITTINGS–MIDGET 1500	H 98.02
HOSE–FLEXIBLE	H 98.02
SWITCH–OIL PRESSURE–ANTI-RUN-ON VALVE	H 98.02

CAB/BODY, PANELS AND FRAMES

BODY SHELL–SPRITE MK 3 AND MIDGET MK 2	I 2
'B' POST–RH	I 2
BODY SHELL AND UNDERFRAME ASSEMBLY (LESS BOOT LID, BONNET TOP, DOORS AND FRONT WINGS)	I 2
FRONT SUSPENSION AND MAIN BEAM	I 4
PANEL–REAR WHEELARCH–RH	I 2
PANEL–SILL OUTER–RH	I 4
PANEL–WING INNER–RH	I 2
PANEL ASSEMBLY–LUGGAGE FLOOR	I 2
PLATE–SILL SIDE–RH $	I 4
SHIELD–MUD–RH	I 4
WHEELARCH–FRONT–RH	I 4
WING ASSEMBLY–REAR–RH	I 2
BODY SHELL–SPRITE MK 4 AND MIDGET MK 3	I 6
'A' POST–RH	I 12
'B' POST–RH $	I 8
BODYSHELL AND UNDERFRAME ASSEMBLY (LESS BOOT LID, BONNET PANEL, DOORS AND FRONT WINGS)	I 6
FRONT SUSPENSION AND MAIN BEAM	I 12
MOTIF 'MIDGET' (SILL)	I 14
MOTIF 'SPRITE' (SILL)	I 14
MOULDING–SILL	I 14
PANEL–SILL OUTER–RH	I 12
PANEL–SILL SIDE–RH $	I 12
PANEL–WING INNER–RH	I 6
PANEL ASSEMBLY–BODY REAR	I 6
PANEL ASSEMBLY–LUGGAGE FLOOR	I 10
WHEELARCH–FRONT–RH	I 12
WING ASSEMBLY–REAR–RH $	I 8
BODY SHELL BLANKING PLUGS	I 16
WING DETAILS	I 18
BADGE–BRITISH LEYLAND	I 20
MOULDING–FRONT WING	I 20
MOULDING–REAR WING	I 20
WING–FRONT–RH	I 18

DOORS AND DOOR WINDOWS

DOORS AND FITTINGS	J 2
DOOR–SEAL–FRONT–UPPER	J 4
DOOR ASSEMBLY–RH	J 2
HANDLE–DOOR PULL	J 2
HINGE $	J 2
PULL–DOOR	J 2
DOOR LOCKS AND HANDLES	J 6
BARREL–LOCK $	J 8
HANDLE–REMOTE CONTROL $	J 6
HANDLE ASSEMBLY–DOOR	J 6
LOCK–DOOR–RH	J 6
LOCK–PRIVATE–RH	J 8
REMOTE CONTROL–LOCK–RH $	J 6
STRIKER–LOCK–RH	J 8
WINDOWS AND WINDOW REGULATORS	J 10
GLASS–DOOR–RH $	J 10
HANDLE–REGULATOR	J 12
REGULATOR–WINDOW–RH	J 10
WINDOW VENTILATORS	J 14
HANDLE–FLAT LOCKING–RH $	J 16
SEAL–VENTILATOR TO DOOR–RH	J 16
VENTILATOR ASSEMBLY–RH $	J 14

BONNET, BOOT LID, TAIL GATE, HOOD

BONNET AND CONTROL	K 2
BADGE–BONNET	K 2
BONNET ASSEMBLY $	K 2
CABLE–BONNET RELEASE $	K 4
CATCH ASSEMBLY–SAFETY $	K 2
HINGE–BONNET $	K 2
MOULDING–BONNET CENTRE	K 2
PIN–BONNET LOCK $	K 4
ROD–BONNET PROP	K 4
BOOT LID AND FITTINGS	K 6

SPRITE MK 3 AND MK 4, MIDGET MK 2 AND MK 3
PAGE INDEX

Item	Page No.
BADGE–BOOT LID–SILVER LETTERS	K 6
BARREL–LOCK	K 8
CARRIER ASSEMBLY–LUGGAGE	K 8
HANDLE ASSEMBLY–LOCKING	K 8
HINGE–BOOT LID–RH	K 8
LID–BOOT	K 6
ROD–BOOT LID PROP	K 8
HOOD–SPRITE MK.3 AND MIDGET MK.2	K 10
HOOD–SPRITE MK.4 AND MIDGET MK.3	K 12
BAG–STOWAGE–HOOD STOWAGE COVER	K 16
COVER ASSEMBLY–HOOD (WITH HEADER RAIL) BLACK	K 12
COVER ASSEMBLY–HOOD STOWAGE	K 16
FRAME–HOOD $	K 14
HARD TOP–SPRITE MK.3 AND MIDGET MK.2–OPTIONAL EXTRA	K 18
HARD TOP–SPRITE MK.4 AND MIDGET MK.3–OPTIONAL EXTRA	K 20
GLASS–QUARTER–LIGHT $	K 20
HARD TOP ASSEMBLY–PRIMED	K 20
RUBBER–SEALING–DOOR	K 22
TONNEAU COVER–SPRITE MK3 AND MIDGET MK2–OPTIONAL EXTRA	K 24
TONNEAU COVER–SPRITE MK 4 AND MIDGET MK 3	K 26
BAG–TONNEAU COVER STOWAGE	K 30
COVER ASSEMBLY–TONNEAU	K 26
FASTENER–ZIP	K 28

RADIATOR, GRILLE AND BUMPERS

RADIATOR GRILLE	L 2
MOTIF–GRILLE–MG	L 4
FRONT BUMPERS	L 6
BAR–BUMPER–FRONT	L 6
EYE–TOWING	H 6.02
OVER-RIDER	L 6
REAR BUMPERS	L 8
BAR–BUMPER–REAR	L 8
REINFORCEMENT–BUMPER FIXING	L 10
REINFORCEMENT–BUMPER FIXING	L 10
BUMPERS–FRONT AND REAR–(C) G-AN6-154101 ON	L 10.02
EYE–TOWING	L 10.02
MOTIF–FRONT BUMPER–SILVER LETTERS	L 10.02
BUMPER FIXINGS AND NUMBER PLATES	L 12
BRACKET–BUMPER MOUNTING	L 12
BRACKET–FRONT NUMBER-PLATE MOUNTING	L 12
BUFFER–BRACKET	L 14
NUMBER-PLATE–FRONT	L 12
NUMBER-PLATE–REAR	L 12

WINDSCREEN, WINDOWS, MIRRORS

WINDSCREEN AND WINDSCREEN FIXINGS	M 2
MIRROR–INTERIOR–DIPPING $	M 8
MIRROR–WING–BOOMERANG TYPE–OPTIONAL EXTRA	M 8
MIRROR ASSEMBLY–DOOR $	M 8
RAIL ASSEMBLY–TOP	M 4
RAIL ASSEMBLY–BOTTOM	M 6
WINDSCREEN WASHER	M 10
CONTROL–WINDSCREEN WASHER $	M 10
JET ASSEMBLY	M 10

FASCIA, HEATER AND VENTILATION

FASCIA DETAILS–NOT N. AMERICA AND SWEDEN	N 2
PANEL–FASCIA–RHD	N 2
TRAY ASSEMBLY–PARCEL–RHD	N 2
FASCIA DETAILS–N. AMERICA AND SWEDEN	N 4
LID–CUBBY BOX	N 6
LIGHT–WARNING–'FASTEN BELTS'	N 4
PANEL–FASCIA $	N 4
PANEL–RADIO MOUNTING	N 4
HEATER UNIT	N 8
BLOWER ASSEMBLY	N 14
HOSE–BLOWER TO INLET	N 16
HOSE–DEMISTER	N 8
HOSE–HEATER TO CONTROL TAP	N 8
HOSE–HEATER TO BLOWER	N 8
MATRIX (WITH SEALS)	N 8
MOTOR	N 14
NOZZLE–DEMISTER–RH	N 12
SWITCH ASSEMBLY–HEATER	N 16
TAP–WATER CONTROL	N 8
TUBE ASSEMBLY–AIR INTAKE	N 14
HEATER FIXINGS	N 20
CABLE–AIR CONTROL $	N 20
CABLE–AIR CONTROL $	N 20
CONTROL ASSEMBLY–ROTARY–AIR VALVE	N 20
FRESH-AIR UNIT–OPTIONAL EXTRA	N 24

TRIMMING DETAILS AND SEATS

TRIM LINERS	O 2
LINER–FOOTWELL	O 2
LINER–SCUTTLE	O 2
LINER–SILL	O 4
LINER ASSEMBLY–DOOR	O 4
PULL–DOOR	O 2
DOOR CHECK STRAP AND DRAUGHT EXCLUDER	O 6
DRAUGHT EXCLUDER–DOOR–60" (152.4MM)	O 6
FINISHER–DRAUGHT EXCLUDER	O 6
STRAP–DOOR CHECK	O 6
REAR LINERS	O 8
LINER ASSEMBLY–REAR BULKHEAD	O 10
REAR COCKPIT FINISHER AND SUN VISOR	O 12
MOULDING–DOOR TOP–RH	O 12
MOULDING–COCKPIT REAR	O 12
VISOR–SUN–RH $	O 12
CARPETS	O 14
ASHTRAY–TUNNEL	O 18
CARPET–REAR WHEELARCH	O 20
CARPET ASSEMBLY–FRONT–RH–RHD	O 14
CARPET ASSEMBLY–FRONT–LH–LHD	O 16
CARPET ASSEMBLY–REAR COMPARTMENT–CENTRE	O 18
CARPET ASSEMBLY–TUNNEL–FRONT	O 18
RECLINING SEATS–HEAD RESTRAINTS AND SEAT BELTS	O 28
BELT–SEAT SET–STATIC (KANGOL) $	O 34
BELT–SEAT SET (KANGOL) $	O 34
COVER–CUSHION	O 30
COVER–SQUAB	O 30
CUSHION–REAR COMPARTMENT	O 34
RESTRAINT–HEAD	O 32
UNIT–CONTROL–SEQUENTIAL SEAT SYSTEM $	O 34
BULK MATERIALS	O 36
MATERIAL–LEATHERCLOTH	O 36
MATERIAL–CARPET	O 36
UNDERFELT–MAT	O 36

ROAD WHEELS AND TOOLS

ROAD WHEELS	P 2
TOOLS	P 4

SPECIAL FITMENT, SPECIAL TUNING

SPECIAL TUNING–ENGINE UNIT	Q 2
BELT–FAN–SHORT	Q 4
CAMSHAFT	Q 2
CRANKSHAFT–NITRIDED	Q 2
GASKET–CYLINDER HEAD	Q 6
GEAR–CAMSHAFT–LIGHTENED	Q 2
HEAD ASSEMBLY–POLISHED–COMPLETE	Q 2
KIT–CHAIN TIMING–DUPLEX	Q 4
KIT–OIL COOLER	Q 6
KIT–SUMP (DEEP)	Q 6
MAIN BEARING SET	Q 2
MANIFOLD–EXHAUST LARGE BORE	Q 6
PISTON ASSEMBLY–ENGINE SET–GRADE 3–9.75 : 1 COMPRESSION RATIO	Q 2
PISTON ASSEMBLY–ENGINE SET–GRADE 3–12 : 1 COMPRESSION RATIO	Q 2
PISTON ASSEMBLY–ENGINE SET–GRADE 3–9.75 : 1 COMPRESSION RATIO–LIGHTWEIGHT FORGED	Q 2
PLUG–SPARKING	Q 4
RING–PISTON–ENGINE SET	Q 2
ROCKER–VALVE (FORGED)	Q 4
SHAFT–VALVE ROCKER–STRENGTHENED	Q 4
SPRING–VALVE	Q 4

SPRITE MK 3 AND MK 4, MIDGET MK 2 AND MK 3
PAGE INDEX

Item	Page No.
SPECIAL TUNING–DISTRIBUTOR –IGNITION AND ENGINE ANCILLARIES	Q 8
DISTRIBUTOR	Q 8
KIT–BLANKING SLEEVE–THERMOSTAT BY-PASS	Q 8
KIT–HIGH TENSION–PLUG–WATER PROOFING	Q 8
PULLEY–DYNAMO FOR REDUCED SPEED	Q 8
SWITCH–IGNITION CUT-OUT	Q 8
SPECIAL TUNING–FLYWHEEL, CLUTCH, GEARBOX, FINAL DRIVE AND AXLE SHAFT	Q 10
CROWN WHEEL AND PINION	Q 10.02
DIFFERENTIAL–LIMITED SLIP	Q 10.02
FLYWHEEL–LIGHTENED–1275cc	Q 10
KIT–GEAR SET–CLOSE RATIO–STRAIGHT CUT	Q 10
PLATE–DRIVEN–CLUTCH	Q 10
SPECIAL TUNING–FUEL SYSTEM	Q 12
KIT–DUAL FUEL PUMP	Q 12
SPECIAL TUNING–CARBURETTER	Q 14
CARBURETTER INSTALLATION	Q 14
KIT–INSTALLATION–CARBURETTER	Q 14
SPECIAL TUNING–CARBURETTER –WEBER TYPE	Q 16
CARBURETTER–WEBER (45 DCOE)	Q 16
KIT–INSTALLATION–WEBER–CARBURETTER	Q 16
SPECIAL TUNING–TWIN CARBURETTER ASSEMBLY	Q 18
CARBURETTER ASSEMBLY–FRONT	Q 18
CARBURETTER ASSEMBLY–REAR	Q 18
CHAMBER AND PISTON ASSEMBLY	Q 18
SPECIAL TUNING–INSTALLATION KIT FOR HS6 CARBURETTERS	Q 22
CABLE–ACCELERATOR	Q 22
KIT–INSTALLATION FOR HS6 CARBURETTER	Q 22
MANIFOLD–INLET	Q 22
SPECIAL TUNING–TWIN HS6 CARBURETTERS	Q 24
CARBURETTER INSTALLATION (HS6)	Q 24
SPECIAL TUNING–SHOCK ABSORBER AND ANTI-ROLL BAR	Q 28
ABSORBER–SHOCK	Q 28
KIT–ANTI-ROLL BAR–0.5625" (14.3MM) DIA. BAR	Q 28
KIT–FRONT SUSPENSION–LOWERING	Q 28
KIT–INSTALLATION–ANTI-ROLL BAR	Q 28
SPECIAL TUNING–BRAKES–ROAD WHEELS–BODYWORK AND LITERATURE	Q 30
JACKET–RALLY–BRITISH LEYLAND	Q 30
KIT–BONNET STRAP	Q 30
KIT–DUAL BRAKING SYSTEM	Q 30
KIT–HEADLAMP COWL	Q 30
KIT–RUBBER TOGGLE–RETAINER	Q 30
SET–BRAKE PAD–DS11 LININGS	Q 30
SPECIAL TUNING DATA SET	Q 30
WHEEL–WIRE–60 SPOKE–13" x 5"	Q 30
WORKSHOP MANUAL	Q 30