
MASTER INDEX

INTRODUCTION INTRODUCTION EINFUHRUNG	1.B
ENGINE MOTEUR MOTOR	1.C
FLYWHEEL AND CLUTCH VOLANT ET EMBRAYAGE SCHWUNGRAD UND KUPPLUNG	1.D
GEARBOX AND PROPSHAFT BOITE DE VITESSES ET CARDAN GETRIEBE UND KARDANWELLE	1.E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS AXE, SUSPENSION, ARBRE DE COMMANDE,ROUES ACHSE, AUFHANGUNG, ANTRIEBSWELLE, RADER	1.F
STEERING DIRECTION LE[illegible]UNG	1.G
BRAKES AND BRAKE CONTROLS FREINS ET COMMANDES BREMSEN UND BEDIENUNGSORGANE	1.H
FUEL, EXHAUST AND EMISSION SYSTEMS ALIMENTATION ET ECHAPPEMENT KRAFTSTOFF UND AUSPUFFANLAGE	1.I
COOLING, HEATING AND AIR CONDITIONING REFROIDISSEMENT, CHAUFFAGE, AERATION KUHLUNG, HEIZUNG UND LUFTUNG	1.K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS ELECTRICITE, ESSUIE GLACE, INSTRUMENTS ELEKTRISCHE, SCHEIBENWISCHER,INSTRUMENTE	1.L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS CHASSIS, SOUBASSEMENT, CABINE CHASSIS TEILE, HILFSRAHMEN, KABINE	2.C
FASCIA, TRIM, SEATS AND FIXINGS TABLEAU DE BORD,GARNITURES INT ET SIEGES ARMATURENBRETT, POLSTERUNG UND SITZ	2.E
MISCELLANEOUS DIVERS VERMISCHT	2.F
NUMERICAL INDEX INDEX NUMERIQUE NUMMERNVERZEICHNIS	2.G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0647


Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
			FRONT BRAKES.			
1	BTA 383		Disc-brake $	2		Disc wheels only
2	BTA 469		Disc-brake $	2		Wire wheels only
3	BTA 370		Bolt-disc to hub $	8		
4	BTA 472		Cover-dust-brake disc-RH $	1		
	BTA 473		Cover-dust-brake-disc-LH $	1		
18	SH 605031		Bolt-dust cover	2		
19	WE 600051		Washer-shakeproof	2		
	BTA 653		UNIT ASSEMBLY-CALLIPER-LH	NLA		Use 17H 9438 with pad GBP 108 and shim 17H 2460
	BTA 652		UNIT ASSEMBLY-CALLIPER-RH	NLA		Use 17H 9439 with pad GBP 108 and shim 17H 2460
5	27H 4353		Bolt-bridge	4		
6	17H 7679		Seal-fluid channel $	2		
7	GBP 108		PAD ASSEMBLY	1SET		
8	17H 7963		Spring-pad retainer	2		
9	PS 610241		Pin-split cotter	4		
10	17H 2460		Shim-pad	4		
11	17H 7917		Plug	2		
12	3H 2428		Screw-bleed	2		

MASTER INDEX

INTRODUCTION 1 B
ENGINE 1 C
FLYWHEEL AND CLUTCH 1 D
GEARBOX AND PROPSHAFT 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1 F
STEERING 1 G
BRAKES AND BRAKE CONTROLS 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS 1 I
COOLING, HEATING AND AIR CONDITIONING 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2 C
FASCIA, TRIM, SEATS AND FIXINGS 2 E
MISCELLANEOUS 2 F
NUMERICAL INDEX 2 G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0647


Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
			FRONT BRAKES–continued			
	17H 9438		UNIT ASSEMBLY-CALLIPER(LESS PADS AND SHIMS)-LH $	1		
13	17H 9439		UNIT ASSEMBLY-CALLIPER(LESS PADS AND SHIMS)-RH $	1		
5	17H 8250		Bolt-bridge $	NLA		Use 27H 4353
5	27H 4353		Bolt-bridge $	4		
6	17H 7679		Seal-fluid channel	2		
12	3H 2428		Screw-bleed	2		
14	8G 8668		Kit-repair-calliper unit $	2		
7	GBP 108		PAD ASSEMBLY $	1SET		
8	17H 7963		Spring-pad retainer $	2		
9	PS 610241		Pin-split cotter	4		
10	17H 2460		Shim-anti-squeal $	4		
	BTA 444		Bolt-calliper mounting	NLA		Use BTA 789 And BTC 114 Together with 1 Off lock plate BTA 792 RH or BTA 793 LH
15	BTA 789		Bolt-calliper mounting $	4		
16	BTC 114		Washer-tab-bolt $	2		
	BTA 792		Lockplate-brake hose-RH $	NLA		
17	BTA 793		Lockplate-brake hose-LH $	1		

MASTER INDEX

INTRODUCTION 1.B
ENGINE 1.C
FLYWHEEL AND CLUTCH 1.D
GEARBOX AND PROPSHAFT 1.E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1.F
STEERING 1.G
BRAKES AND BRAKE CONTROLS 1.H
FUEL, EXHAUST AND EMISSION SYSTEMS 1.I
COOLING, HEATING AND AIR CONDITIONING 1.K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1.L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2.C
FASCIA, TRIM, SEATS AND FIXINGS 2.E
MISCELLANEOUS 2.F
NUMERICAL INDEX 2.G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0648


Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
			REAR BRAKES			
1	37H 8804		Plate-brake-RH $	1		
	37H 8805		Plate-brake-LH $	1		
20	SH 605071		Screw	8		
21	GHF 222		Locknut	8		
2	GBS 625		SHOE ASSEMBLY-BRAKE $	2STS		
22	18G 8329		LINING AND RIVET ASSEMBLY	1BOX		
4	17H 7947		Spring-shoe return-cylinder end-RH $	1		
5	17H 7948		Spring-shoe return-cylinder end-LH $	1		
6	17H 7621		Spring-shoe return-adjuster end $	2		
7	17H 7618		Tappet $	4		
8	17H 7619		Wedge $	2		
9	GWC 1129		CYLINDER ASSEMBLY-WHEEL $	2		
11	17H 7623		Screw-bleed $	NLA		Use 513118
11	513118		Screw-bleed $	2		
12	BHM 7054		Kit-repair $	2		
13	17H 7613		Washer-Belleville-wheel cylinder fixing $	2		
14	17H 7622		Circlip-wheel cylinder fixing $	2		
15	17H 2824		Lever-handbrake-RH $	1		
	17H 2825		Lever-handbrake-LH $	1		
16	17H 7612		Boot-handbrake lever $	2		
17	2A 7168		Drum-brake $	2		
3	SF 604061		Screw	4		
10	FNZ 506		Nut	8		Wire wheels ONLY
18	BTA 493		Washer-tab $	4		Wire wheels ONLY
19	2A 7228		Plug-drum(rubber)	2		

MASTER INDEX

INTRODUCTION ..... 1 B
ENGINE ..... 1 C
FLYWHEEL AND CLUTCH ..... 1 D
GEARBOX AND PROPSHAFT ..... 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS ..... 1 F
STEERING ..... 1 G
BRAKES AND BRAKE CONTROLS ..... 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS ..... 1 I
COOLING, HEATING AND AIR CONDITIONING ..... 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS ..... 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS ..... 2 C
FASCIA, TRIM, SEATS AND FIXINGS ..... 2 E
MISCELLANEOUS ..... 2 F
NUMERICAL INDEX ..... 2 G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0652

BRAKE PEDAL DETAILS


Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
1	AHA 9723		PEDAL ASSEMBLY-BRAKE $	1	(C)G-AN6-154101 TO 212000	RHD
16	CHA 791		PEDAL ASSEMBLY-BRAKE $	1	(C)G-AN6-212001 ON	RHD
	AHA 9723		PEDAL ASSEMBLY-BRAKE $	1		LHD
2	LBS 810		Bush	1		
3	AHA 5326		Pad-pedal(rubber)	1		
4	AHA 8075		Bolt-brake and clutch pedal $	1		
5	GHF 333		Washer-spring-bolt	1		
6	WA 112081		Washer-plain-bolt	1		
7	FNZ 506		Nut-bolt	1		
8	AAA 1628		Spring-pedal return $	1		Use BHH 2387 For this Application
8	BHH 2387		Spring-pedal return $	1		
9	AHA 8408		Box-pedal	1	(C)G-AN6-154101 TO 200000	Single line System
17	CHA 375		Box-pedal	1		Dual line system
18	AHA 8408		Box-pedal	1	(C)G-AN6-200001 ON (Except California)	
17	CHA 375		Box-pedal	1	(C)G-AN6-200001 TO 212000(California)	
18	AHA 8408		Box-pedal	1	(C)G-AN6-212001 ON (California)	
10	CHA 333		Cover-top-pedal box	1		
11	AHA 8073		Seal-cover-box-pedal	1		
12	AHA 8072		Gasket-box-pedal	1		
13	HZS 405		Screw-box-pedal	6		
14	SE 604051		Screw-box-pedal	A/R		
15	GHF 132		Washer-spring	8		

MASTER INDEX

INTRODUCTION 1 B
ENGINE 1 C
FLYWHEEL AND CLUTCH 1 D
GEARBOX AND PROPSHAFT 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1 F
STEERING 1 G
BRAKES AND BRAKE CONTROLS 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS 1 I
COOLING, HEATING AND AIR CONDITIONING 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2 C
FASCIA, TRIM, SEATS AND FIXINGS 2 E
MISCELLANEOUS 2 F
NUMERICAL INDEX 2 G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



BRAKE MASTER CYLINDER

SINGLE LINE SYSTEM

Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
1	GMC 113		CYLINDER AND SUPPLY TANK ASSEMBLY-BRAKE MASTER	NLA	.....	Use GMC 151
2	27H 7751		Spring-piston return	1		
3	9025		Retainer-spring	NLA	.....	Use 506670
3	506670		Retainer-spring	1		
4	17H 7560		Circlip	1	(C)G-AN6-154101 TO (+)	
5	27H 8459		Push-rod	NLA		Use AAU 3469
5	AAU 3469		Push-rod	1		
6	17H 6861		Cap-filler	NLA	.....	Use 513123
6	513123		Cap-filler	1		
7	8G 8258		Kit-repair-brake master cylinder	1		
1	GMC 151		CYLINDER AND SUPPLY TANK ASSEMBLY-BRAKE MASTER	1	.....	Identify by Two concentric Circles
2	27H 7751		Spring-piston return	1		
3	9025		Retainer-spring	NLA	(C)G-AN6(+)TO 200000	Use 506670
3	506670		Retainer-spring	1		
4	17H 7560		Circlip	1		
5	AAU 3469		Push rod	1		
6	513123		Cap-filler	1		
7	BHM 7125		Kit-cylinder repair	1		
14	GMC 166		CYLINDER ASSEMBLY-BRAKE MASTER	1		
20	AAU 8105		Spring-return	1		
21	AAU 8106		Retainer-spring	1	(C)G-AN6-200001 TO 212000	
4	17H 7560		Circlip	1		
5	27H 8459		Push-rod	NLA	.....	Use AAU 3469
5	AAU 3469		Push-rod	1		
7	BHM 7125		Kit-cylinder repair	1		

(+) Change point not known


MG0650

MASTER INDEX

INTRODUCTION ..... 1 B
ENGINE ..... 1 C
FLYWHEEL AND CLUTCH ..... 1 D
GEARBOX AND PROPSHAFT ..... 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS ..... 1 F
STEERING ..... 1 G
BRAKES AND BRAKE CONTROLS ..... 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS ..... 1 I
COOLING, HEATING AND AIR CONDITIONING ..... 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS ..... 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS ..... 2 C
FASCIA, TRIM, SEATS AND FIXINGS ..... 2 E
MISCELLANEOUS ..... 2 F
NUMERICAL INDEX ..... 2 G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0650


Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
			BRAKE MASTER CYLINDER-continued			
			SINGLE LINE SYSTEM-continued			
8	CLZ 513		Pin-clevis	1		
9	GHF 301		Washer-plain-pin	1		
10	SH 605071		Screw-cylinder	1	(CIG-AN6-154101 TO 212000	
11	GHF 301		Washer-plain-screw	1		
12	GHF 332		Washer-spring-screw	1		
13	FNZ 505		Nut-screw	1		
15	BHA 4810		RESERVOIR ASSEMBLY-FLUID	1		
16	AAU 3815		Cap-filler	1		
	37H 6944		Hose-reservoir to master cylinder-5"(127mm)long	A R	(CIG-AN6-200001 TO 212000	Use CHA 793 for This application
17	CHA 793		Hose-reservoir to master cylinder	1		
18	AAU 1711		Clip-hose to cylinder	1		
19	ADU 1169		Clip-hose to reservoir	1		

MASTER INDEX

INTRODUCTION 1 B
ENGINE 1 C
FLYWHEEL AND CLUTCH 1 D
GEARBOX AND PROPSHAFT 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1 F
STEERING 1 G
BRAKES AND BRAKE CONTROLS 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS 1 I
COOLING, HEATING AND AIR CONDITIONING 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2 C
FASCIA, TRIM, SEATS AND FIXINGS 2 E
MISCELLANEOUS 2 F
NUMERICAL INDEX 2 G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0567A

BRAKE PIPES AND FITTINGS

SINGLE LINE SYSTEM

Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
1	37H 7147	M	Pipe-master cylinder to RH front hose 33"(83.8cm)	A R		
2	3H 2249		Nut-tube	1		
3	11D 5050		Nut-tube	1		
4	37H 7147	M	Pipe-master cylinder to 3-way 60"(152.4cm)	A R		
2	3H 2249		Nut-tube	2		
5	37H 7147	M	Pipe-3-way to LH front hose 11.5"(29.2cm)	A R		
2	3H 2249		Nut-tube	1		
3	11D 5050		Nut-tube	1		
6	37H 7147	M	Pipe-3-way to rear hose 81"(205.7cm)	A/R		(CIG-AN6-154101 TO 212000
2	3H 2249		Nut-tube	1		
3	11D 5050		Nut-tube	1		
7	37H 7147	M	Pipe-3-way connection to RH rear brake-22"(56cm)	A R		
2	3H 2249		Nut-tube	2		
8	37H 7147	M	Pipe-3-way connection to LH rear brake-30"(77cm)	A/R		
2	3H 2249		Nut-tube	2		
9	3H 2424		Connection-3-way-front	1		
10	GHF 101		Bolt	1		
11	GHF 331		Washer-spring	1		
9	3H 2424		Connection-3-way-rear	1		
12	BH 604101		Bolt	1		
11	GHF 331		Washer-spring	1		
13	GHF 200		Nut	1		
14	ACA 5375		Strap-pipe to rear axle	NLA		

NOTE -
Part numbers with suffix M are supplied in multiples of metres(39.37")


MG0567A

MASTER INDEX

INTRODUCTION	1 B
ENGINE	1 C
FLYWHEEL AND CLUTCH	1 D
GEARBOX AND PROPSHAFT	1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS	1 F
STEERING	1 G
BRAKES AND BRAKE CONTROLS	1 H
FUEL, EXHAUST AND EMISSION SYSTEMS	1 I
COOLING, HEATING AND AIR CONDITIONING	1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS	1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS	2 C
FASCIA, TRIM, SEATS AND FIXINGS	2 E
MISCELLANEOUS	2 F
NUMERICAL INDEX	2 G

GROUP INDEX

BRAKE MASTER CYLINDER	H06
BRAKE MASTER CYLINDER	H10
DUAL LINE SYSTEM	H10
KIT-CYLINDER REPAIR	H06
KIT-REPAIR-MASTER CYLINDER	H10
SINGLE LINE SYSTEM	H06
BRAKE PEDAL DETAILS	H05
BRAKE PIPES AND FITTINGS	H08
BRAKE PIPES AND FITTINGS	H11
DUAL LINE SYSTEM	H11
KIT-REPAIR	H12
SINGLE LINE SYSTEM	H08
SWITCH ASSEMBLY-PRESSURE	H12
SWITCH-STOP LIGHT	H09
SWITCH-STOPLIGHT	H13
FRONT BRAKES	H02
KIT-REPAIR-CALLIPER UNIT	H03
PAD ASSEMBLY	H02
PAD ASSEMBLY	H03
HAND BRAKE LEVER AND LINKAGE	H14
SWITCH AND LEADS-HANDBRAKE	H14
REAR BRAKES	H04
KIT-REPAIR	H04
SHOE ASSEMBLY-BRAKE	H04



MG0567A

BRAKE PIPES AND FITTINGS-continued

SINGLE LINE SYSTEM-continued


Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
15	GBH 139		Hose-front brake $	NLA	(C)G-AN6-154101 TO 162564	Use GBH 157
15	GBH 157		Hose-front brake $	2	(C)G-AN6-162565 TO 212000	
16	11D 5264		Bolt-banjo $	2		
17	7H 7851		Connector-banjo	1	(C)G-AN6-154101 TO 212000	
18	3H 550		Gasket-bolt $	3		
19	1G 9198		Plate-locking-hose-rear	1		
	GBH 109		Hose-rear brake	NLA	(C)G-AN6-154101 TO 162564	Use GBH 158
20	GBH 158		Hose-rear brake $	1	(C)G-AN6-162565 TO 212000	
21	3H 2287		Gasket-hose and banjo bolt	NLA		Use 233220
21	233220		Gasket-hose and banjo bolt	4	(C)G-AN6-154101 TO 212000	
22	GHF 202		Nut	3		
23	GHF 323		Washer-shakeproof	3		
24	PCR 307		Clip-pipe to rear crossmember	1		
25	PCR 307		Clip-pipe to footwell	1		
26	CZK 5108		Screw-clips	NLA		
27	WL 700101		Washer-spring	2		
28	GHF 306		Washer-plain	2		
29	6K 35		Clip-pipe to floor	2		
30	CP 106051		Clip-pipe RH to pedal box	1	(C)G-AN6-154101 TO 212000	
31	PCR 307		Clip-pipe to footwell top	2		
32	GHF 425		Screw-clip to footwell	1		
33	GHF 426		Screw-clip to footwell	1		
34	PCR 307		Clip-pipe to bulkhead	2		
35	PMZ 308		Screw-clip	2		
36	WC 702101		Washer-plain	2		
37	WL 700101		Washer-spring	2		
38	GHF 206		Nut	2		
39	BHA 4675		Switch-stop light	1		
40	NH 606041		Nut	NLA		Use GHF 202
40	GHF 202		Nut	1		

MASTER INDEX

INTRODUCTION 1 B
ENGINE 1 C
FLYWHEEL AND CLUTCH 1 D
GEARBOX AND PROPSHAFT 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1 F
STEERING 1 G
BRAKES AND BRAKE CONTROLS 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS 1 I
COOLING, HEATING AND AIR CONDITIONING 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2 C
FASCIA, TRIM, SEATS AND FIXINGS 2 E
MISCELLANEOUS 2 F
NUMERICAL INDEX 2 G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0649

BRAKE MASTER CYLINDER

DUAL LINE SYSTEM


Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
1	37H 2760		CYLINDER AND SUPPLY TANK ASSEMBLY-BRAKE MASTER(LESS PUSH-ROD) $	NLA		Use GMC 170
1	GMC 170		CYLINDER AND SUPPLY TANK ASSEMBLY-BRAKE MASTER(LESS PUSH ROD) $	1		
21	37H 2763		Spring-piston $	1		
2	27H 8442		Pin-link-piston $	1		
3	27H 8443		Retainer-spring $	1		
4	37H 5912		Washer-stop $	1		
5	27H 8445		Circlip $	1		
6	27H 8446		Washer-cap $	1		
7	27H 8445		Circlip-bearing	1		
8	37H 2764		Spring-primary piston $	1		
9	27H 8449		Retainer-spring $	1		
10	27H 8450		Ring-securing $	1		
11	27H 8453		Body-trap valve $	2		
12	27H 8454		Clip-trap valve $	NLA		Use 514151
12	514151		Clip-trap valve $	2		
13	27H 8456		Adaptor-outlet $	2		
14	7H 7520		Bolt-fluid tank $	4		
20	GHF 321		Washer-bolt	4		
	37H 7022		Cap-filler $	NLA		Use AAU 3815
15	AAU 3815		Cap-filler (with warning instructions) $	1		
16	18G 858?		Kit-repair-master cylinder $	1		
17	37H 2172		Seal-filler cap $	NLA		
18	BHA 5132		Push-rod $	1		
19	CLZ 513		Pin-clevis	1		
22	GHF 301		Washer-plain-pin	1		
23	GHF 332		Washer-spring-cylinder	1		
24	FNZ 505		Nut-cylinder	1		

MASTER INDEX

INTRODUCTION ..... 1 B
ENGINE ..... 1 C
FLYWHEEL AND CLUTCH ..... 1 D
GEARBOX AND PROPSHAFT ..... 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS ..... 1 F
STEERING ..... 1 G
BRAKES AND BRAKE CONTROLS ..... 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS ..... 1 I
COOLING, HEATING AND AIR CONDITIONING ..... 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS ..... 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS ..... 2 C
FASCIA, TRIM, SEATS AND FIXINGS ..... 2 E
MISCELLANEOUS ..... 2 F
NUMERICAL INDEX ..... 2 G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0565B

Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
			BRAKE PIPES AND FITTINGS			
			DUAL LINE SYSTEM			
1	37H 7147	M	Pipe-master cylinder to pressure switch-front 66"(167 6cm)long $	A/R		RHD
2	BHA 4706		Nut-tube	1		RHD
3	3H 2249		Nut-tube	1		RHD
4	37H 7147	M	Pipe-master cylinder to pressure switch-rear 61"(154 9cm)long $	A/R		RHD
3	3H 2249		Nut-tube	2		RHD
1	37H 7147	M	Pipe-master cylinder to pressure switch-front 15 5"(39 4cm)long $	A/R		LHD
2	BHA 4706		Nut-tube	1		LHD
3	3H 2249		Nut-tube	1		LHD
4	37H 7147	M	Pipe-master cylinder to pressure switch-rear 17 5"(44 5cm)long $	A/R		LHD
3	3H 2249		Nut-tube	2		LHD
5	37H 7147	M	Pipe-pressure switch to front brake hose-RH-41" (104 1cm)long $	A/R		
6	11D 5050		Nut-tube	1		
2	BHA 4706		Nut-tube	1		
7	37H 7147	M	Pipe-pressure switch to front brake hose-LH-10"(25 4cm)long $	A/R		
6	11D 5050		Nut-tube	1		
2	BHA 4706		Nut-tube	1		


Note -Part numbers listed with the suffix M are supplied in multiples of Metres (39 37")

MASTER INDEX

INTRODUCTION 1 B
ENGINE 1 C
FLYWHEEL AND CLUTCH 1 D
GEARBOX AND PROPSHAFT 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1 F
STEERING 1 G
BRAKES AND BRAKE CONTROLS 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS 1 I
COOLING, HEATING AND AIR CONDITIONING 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2 C
FASCIA, TRIM, SEATS AND FIXINGS 2 E
MISCELLANEOUS 2 F
NUMERICAL INDEX 2 G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0565B

BRAKE PIPES AND FITTINGS-continued

DUAL LINE SYSTEM-continued

Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
8	37H 7147	M	Pipe-pressure switch to rear brake hose-81"(205 7cm)long $	A/R		
6	11D 5050		Nut-tube	1		
3	3H 2249		Nut-tube	1		
9	37H 7147	M	Pipe-3-way connection to RH rear brake-22"(56cm)long $	A/R		
3	3H 2249		Nut-tube	2		
10	37H 7147	M	Pipe-3-way connection to LH rear brake-30"(77cm)long $	A/R		
3	3H 2249		Nut-tube	2		
11	AAU 2583		SWITCH ASSEMBLY-PRESSURE FAILURE $	1		
45	AAU 2454		Switch	1		
12	37H 4652		Cap-end	1	(C)G-AN6-212001 ON	RHD
43	BAU 1688		Kit-repair	1		Use BAU 1775
43	BAU 1775		Kit-repair $	1		
44	13H 5905		SWITCH ASSEMBLY-PRESSURE FAILURE $	1	(C)G-AN6-154101 TO 166303	
13	18G 8353		Kit-repair $	1		LHD
11	AAU 2583		SWITCH ASSEMBLY-PRESSURE FAILURE $	1		
45	AAU 2454		Switch	1		
12	37H 4652		Cap-end	1	(C)G-AN6-166304 ON	
43	BAU 1688		Kit-repair $	1		Use BAU 1775
43	BAU 1775		Kit-repair $	1		
14	GHF 101		Bolt	1		
15	GHF 331		Washer-spring	1		
16	3H 2424		Connection-3-way-rear $	1		
17	BH 604101		Bolt	1		
18	GHF 331		Washer-spring	NLA		
19	GHF 200		Nut	1		
20	ACA 5375		Strap-pipe to rear axle	NLA		

NOTE Part nos with suffix 'M' are supplied in multiples of metres(39 37")


MG0565B

MASTER INDEX

INTRODUCTION 1 B
ENGINE 1 C
FLYWHEEL AND CLUTCH 1 D
GEARBOX AND PROPSHAFT 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1 F
STEERING 1 G
BRAKES AND BRAKE CONTROLS 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS 1 I
COOLING, HEATING AND AIR CONDITIONING 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2 C
FASCIA, TRIM, SEATS AND FIXINGS 2 E
MISCELLANEOUS 2 F
NUMERICAL INDEX 2 G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0565B

BRAKE PIPES AND FITTINGS-continued

DUAL LINE SYSTEM-continued


Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
21	GBH 139		Hose-front brake	NLA	(C)G-AN6-154101 TO 162564	Use GBH 157
21	GBH 157		Hose-front brake $	2	(C)G-AN6-162565 ON	
22	11D 5264		Bolt-banjo $	2		
23	3H 550		Gasket-bolt $	2		
24	GBH 109		Hose-rear brake	NLA	(C)G-AN6-154101 TO 162564	Use GBH 158
24	GBH 158		Hose-rear brake $	1	(C)G-AN6-162565 ON	
25	3H 2287		Gasket-hose $	NLA		Use 233220
25	233220		Gasket-hose $	3		
26	GHF 202		Nut	3		
27	GHF 323		Washer-shakeproof	3		
28	623312		Clip-brake pipe to frame	NLA		Use CRC 1250
28	CRC 1250		Clip-brake pipe to frame	2		
29	PCR 307		Clip-brake pipe to tunnel	2		
30	AHA 8683		Clip-pipe	NLA		
31	AHH 6247		Spacer-pipe to cover plate bolt	NLA		
32	GHF 200		Nut	1		
33	GHF 300		Washer-plain	1		
34	GHF 331		Washer-spring	1		
35	PMZ 307		Screw	2		
36	GHF 306		Washer-plain	2		
37	LNZ 203		Locknut	2		
38	WL 700101		Washer-spring	2		
39	GHF 206		Nut	2		
40	BHA 4675		Switch-stoplight $	1		
41	NT 606041		Nut	1		
42	13H 9593		Clip-double-pipes to footwell and dash panel front	5		RHD

MASTER INDEX

INTRODUCTION 1.B
ENGINE 1.C
FLYWHEEL AND CLUTCH 1.D
GEARBOX AND PROPSHAFT 1.E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1.F
STEERING 1.G
BRAKES AND BRAKE CONTROLS 1.H
FUEL, EXHAUST AND EMISSION SYSTEMS 1.I
COOLING, HEATING AND AIR CONDITIONING 1.K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1.L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2.C
FASCIA, TRIM, SEATS AND FIXINGS 2.E
MISCELLANEOUS 2.F
NUMERICAL INDEX 2.G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0651

HAND BRAKE LEVER AND LINKAGE


Illus	Part Number	123456 Description	Quantity	Change Point	Remarks
1	AHA 6406	HAND BRAKE ASSEMBLY $	NLA	(C)G-AN6-154101 TO 164303	Use CHA 567
2	CHA 567	HAND BRAKE ASSEMBLY $	1	(C)G-AN6-166304 ON	
3	17H 7890	Plunger-thumb $	1		
4	7H 5951	Washer-plunger(rubber) $	1		
5	17H 2093	Rod-pawl $	NLA		
6	AWZ 104	Washer-anti-rattle	1		
7	7H 5947	Ratchet and tube $	1		
8	GHF 202	Nut-main spindle	1		
9	17H 2091	Washer-anti-rattle-main spindle $	1		
10	GHF 323	Washer-shakeproof-main spindle	1		
11	AAU 2492	Switch and leads-handbrake	1	(C)G-AN6-166304 ON	
12	88G 295	Screw-handbrake to bracket $	2		
13	2A 7291	Bracket-handbrake mounting $	1		
14	SH 605051	Screw-bracket	3		
15	GHF 332	Washer-spring	3		
16	2A 7308	CABLE ASSEMBLY-HANDBRAKE $	1		
17	UHN 105	Lubricator-cable	1		
18	NT 607041	Locknut	2		
19	CLZ 515	Pin-clevis	1		
20	GHF 301	Washer-plain	1		
21	CLZ 414	Pin-clevis	1		
22	GHF 300	Washer-plain	1	(C)G-AN6-154101 TO 182000	
23	ATA 7320	Support-balance lever $	1		
24	SH 605061	Screw-support to axle	2		
25	PMZ 105	Washer-plain	2		
26	LWZ 305	Washer-spring	2		
27	GHF 201	Nut	2		
28	2A 7058	Carrier-balance lever $	1		
29	2A 7057	Lever-balance $	1		
30	2K 5820	Washer-balance lever(felt)	1		
31	UHN 490	Lubricator-balance lever	1		

MASTER INDEX

INTRODUCTION 1.B
ENGINE 1.C
FLYWHEEL AND CLUTCH 1.D
GEARBOX AND PROPSHAFT 1.E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1.F
STEERING 1.G
BRAKES AND BRAKE CONTROLS 1.H
FUEL, EXHAUST AND EMISSION SYSTEMS 1.I
COOLING, HEATING AND AIR CONDITIONING 1.K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1.L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2.C
FASCIA, TRIM, SEATS AND FIXINGS 2.E
MISCELLANEOUS 2.F
NUMERICAL INDEX 2.G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04



MG0651

Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
			HAND BRAKE LEVER AND LINKAGE-continued			
32	BTA 498		Cross-rod-RH $	1		Disc wheels
	BTA 497		Cross-rod-LH $	1		
32	BTA 495		Cross-rod-RH $	1		Wire wheels
	BTA 494		Cross-rod-LH $	1	(C)G-AN6-154101 TO 182000	
33	CLZ 314		Pin-cross-rod to balance lever	NLA		
34	6K 690		Washer-pin(felt)	4		
35	2K 6930		Pin-cross-rod to brake $	2		
36	2K 5291		Washer-pin(felt)	4		
37	CHA 638		Cable and rod-handbrake	1		Disc wheels
38	CHA 634		Cable and rod-handbrake	1		Wire wheels
19	CLZ 514		Pin-clevis	1		
20	GHF 301		Washer-plain-pin	1		
14	SH 604041		Screw-cable clip	1		
22	GHF 300		Washer-plain-pin	2		
26	GHF 331		Washer-spring-screw	1	(C)G-AN6-182001 ON	
27	GHF 200		Nut-screw	1		
14	GHF 117		Screw-strap	2		
26	GHF 331		Washer-spring	2		
14	SH 605061		Screw-clamp	1		
26	GHF 332		Washer-spring-screw	1		
22	GHF 300		Washer-plain-pin	2		
21	CLZ 411		Pin-clevis	2		

MASTER INDEX

INTRODUCTION ..... 1 B
ENGINE ..... 1 C
FLYWHEEL AND CLUTCH ..... 1 D
GEARBOX AND PROPSHAFT ..... 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS ..... 1 F
STEERING ..... 1 G
BRAKES AND BRAKE CONTROLS ..... 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS ..... 1 I
COOLING, HEATING AND AIR CONDITIONING ..... 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS ..... 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS ..... 2 C
FASCIA, TRIM, SEATS AND FIXINGS ..... 2 E
MISCELLANEOUS ..... 2 F
NUMERICAL INDEX ..... 2 G

GROUP INDEX

BRAKE MASTER CYLINDER H06
BRAKE MASTER CYLINDER H10
DUAL LINE SYSTEM H10
KIT-CYLINDER REPAIR H06
KIT-REPAIR-MASTER CYLINDER H10
SINGLE LINE SYSTEM H06
BRAKE PEDAL DETAILS H05
BRAKE PIPES AND FITTINGS H08
BRAKE PIPES AND FITTINGS H11
DUAL LINE SYSTEM H11
KIT-REPAIR H12
SINGLE LINE SYSTEM H08
SWITCH ASSEMBLY-PRESSURE H12
SWITCH-STOP LIGHT H09
SWITCH-STOPLIGHT H13
FRONT BRAKES H02
KIT-REPAIR-CALLIPER UNIT H03
PAD ASSEMBLY H02
PAD ASSEMBLY H03
HAND BRAKE LEVER AND LINKAGE H14
SWITCH AND LEADS-HANDBRAKE H14
REAR BRAKES H04
KIT-REPAIR H04
SHOE ASSEMBLY-BRAKE H04