
MASTER INDEX

INTRODUCTION INTRODUCTION EINFUHRUNG	1.B
ENGINE MOTEUR MOTOR	1.C
FLYWHEEL AND CLUTCH VOLANT ET EMBRAYAGE SCHWUNGRAD UND KUPPLUNG	1.D
GEARBOX AND PROPSHAFT BOITE DE VITESSES ET CARDAN GETRIEBE UND KARDANWELLE	1.E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS AXE, SUSPENSION, ARBRE DE COMMANDE,ROUES ACHSE, AUFHANGUNG, ANTRIEBSWELLE RADER	1.F
STEERING DIRECTION LENKUNG	1.G
BRAKES AND BRAKE CONTROLS FREINS ET COMMANDES BREMSEN UND BEDIENUNGSORGANE	1.H
FUEL, EXHAUST AND EMISSION SYSTEMS ALIMENTATION ET ECHAPPEMENT KRAFTSTOFF UND AUSPUFFANLAGE	1.I
COOLING, HEATING AND AIR CONDITIONING REFROIDISSEMENT, CHAUFFAGE, AERATION KUHLUNG, HEIZUNG UND LUFTUNG	1.K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS ELECTRICITE, ESSUIE GLACE, INSTRUMENTS ELEKTRISCHE, SCHEIBENWISCHER,INSTRUMENTE	1.L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS CHASSIS, SOUBASSEMENT, CABINE CHASSIS TEILE, HILFSRAHMEN, KABINE	2.C
FASCIA, TRIM, SEATS AND FIXINGS TABLEAU DE BORD,GARNITURES INT ET SIEGES ARMATURENBRETT, POLSTERUNG UND SITZ	2.E
MISCELLANEOUS DIVERS VERMISCHT	2.F
NUMERICAL INDEX INDEX NUMERIQUE NUMMERNVERZEICHNIS	2.G

GROUP INDEX

ALTERNATOR AND FIXINGS	L05
BELT-FAN	L05
BATTERY AND FIXINGS	N03
COURTESY LIGHTS	L13
DISTRIBUTOR-NOT USA	L02
DISTRIBUTOR-USA AND CANADA	L03
FUSE BOX AND RELAY	N02
HEADLAMPS	L07
KIT-SCREW-TRIMMER	L07
HORN AND CONTROLS	M03
INSTRUMENT WARNING LIGHTS	M08
INSTRUMENTS	M04
LAMP-REFLEX	L11
LAMP-REVERSE	L10
LAMP-SIDE AND FLASHER	L08
NUMBER PLATE LAMPS	L12
OIL PRESSURE GAUGE PIPES	M09
SWITCH-OIL PRESSURE-ANTI RUN-ON	M09
SWITCH-OIL-PRESSURE	M09
POWER UNIT ELECTRICS	L04
SWITCH-INHIBITOR(SEAT BELT)	L04
SWITCH-REVERSE LIGHT	L04
RADIO FITTINGS	N04
REAR FOG LAMPS	L14
STARTER AND FIXINGS	L06
STOP/TAIL LAMPS	L09
SWITCHES-(USA TYPES)	M12
LIGHT-WARNING-BRAKE	M14
LIGHT-WARNING'FASTEN BELTS'	M14
LIGHTER ASSEMBLY-CIGAR	M14
UNIT-FLASHER	M13
UNIT-HAZARD WARNING	M14
SWITCHES-RHD	M10
LIGHT-BRAKE WARNING	M11
LIGHTER ASSEMBLY-CIGAR	M11
UNIT-FLASHER-HAZARD WARNING	M11
WINDSCREEN WASHER	M02
WINDSCREEN WIPERS-LHD	L17
WINDSCREEN WIPERS-RHD	L15
WIRING CABLES AND FITTINGS	M15

Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
			FUSE BOX AND RELAY			
1	37H 4727		BOX ASSEMBLY-FUSE	1		
2	GFS 35		Fuse 35 amp(retail pack)	1 PK		
3	SE 910321		Screw	2		
4	WL 700101		Washer-spring	2		
5	563417		Relay-starter motor solenoid	1	(C)G-AN6-154100 TO 159053	N America
6	13H 9475		Relay-battery cut-off	1	(C)G-AN6-166304 ON	N America




MH0706

MASTER INDEX

INTRODUCTION 1 B
ENGINE 1 C
FLYWHEEL AND CLUTCH 1 D
GEARBOX AND PROPSHAFT 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1 F
STEERING 1 G
BRAKES AND BRAKE CONTROLS 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS 1 I
COOLING, HEATING AND AIR CONDITIONING 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2 C
FASCIA, TRIM, SEATS AND FIXINGS 2 E
MISCELLANEOUS 2 F
NUMERICAL INDEX 2 G

GROUP INDEX

ALTERNATOR AND FIXINGS L05
BELT-FAN L05
BATTERY AND FIXINGS N03
COURTESY LIGHTS L13
DISTRIBUTOR-NOT USA L02
DISTRIBUTOR-USA AND CANADA L03
FUSE BOX AND RELAY N02
HEADLAMPS L07
KIT-SCREW-TRIMMER L07
HORN AND CONTROLS M03
INSTRUMENT WARNING LIGHTS M08
INSTRUMENTS M04
LAMP-REFLEX L11
LAMP-REVERSE L10
LAMP-SIDE AND FLASHER L08
NUMBER PLATE LAMPS L12
OIL PRESSURE GAUGE PIPES M09
SWITCH-OIL PRESSURE-ANTI RUN-ON M09
SWITCH-OIL-PRESSURE M09
POWER UNIT ELECTRICS L04
SWITCH-INHIBITOR(SEAT BELT) L04
SWITCH-REVERSE LIGHT L04
RADIO FITTINGS NC4
REAR FOG LAMPS L14
STARTER AND FIXINGS L06
STOP/TAIL LAMPS L09
SWITCHES-(USA TYPES) M12
LIGHT-WARNING-BRAKE M14
LIGHT-WARNING FASTEN BELTS M14
LIGHTER ASSEMBLY-CIGAR M14
UNIT-FLASHER M13
UNIT-HAZARD WARNING M14
SWITCHES-RHD M10
LIGHT-BRAKE WARNING M11
LIGHTER ASSEMBLY-CIGAR M11
UNIT-FLASHER-HAZARD WARNING M11
WINDSCREEN WASHER M02
WINDSCREEN WIPERS-LHD L17
WINDSCREEN WIPERS-RHD L15
WIRING CABLES AND FITTINGS M15



MK0235

BATTERY AND FIXINGS.

Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
			BATTERY			
	GBY 2201		Premium	1		
	GBY 2001		Activator	1		
	GBY 2601		Maintenance free	1		
1	2K 8645		Screw-terminal	2		
2	ACA 9673		Tray-battery	1		
3	34G 2065		Bar-battery	1		
4	37H 3743	M	Packing-bar to battery	A/R		
5	AHA 8674		Rod-battery	1		
6	GHF 331		Washer-spring	2		
7	GHF 200		Nut	2		


NOTE -
Part numbers with suffix 'M' are supplied in multiples of metres(39.37")

MASTER INDEX

INTRODUCTION 1 B
ENGINE 1 C
FLYWHEEL AND CLUTCH 1 D
GEARBOX AND PROPSHAFT 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1 F
STEERING 1 G
BRAKES AND BRAKE CONTROLS 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS 1 I
COOLING, HEATING AND AIR CONDITIONING 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2 C
FASCIA, TRIM, SEATS AND FIXINGS 2 E
MISCELLANEOUS 2 F
NUMERICAL INDEX 2 G

GROUP INDEX

ALTERNATOR AND FIXINGS L05
BELT-FAN L05
BATTERY AND FIXINGS N03
COURTESY LIGHTS L13
DISTRIBUTOR-NOT USA L02
DISTRIBUTOR-USA AND CANADA L03
FUSE BOX AND RELAY N02
HEADLAMPS L07
KIT-SCREW-TRIMMER L07
HORN AND CONTROLS M03
INSTRUMENT WARNING LIGHTS M08
INSTRUMENTS M04
LAMP-REFLEX L11
LAMP-REVERSE L10
LAMP-SIDE AND FLASHER L08
NUMBER PLATE LAMPS L12
OIL PRESSURE GAUGE PIPES M09
SWITCH-OIL PRESSURE-ANTI RUN-ON M09
SWITCH-OIL-PRESSURE M09
POWER UNIT ELECTRICS L04
SWITCH-INHIBITOR(SEAT BELT) L04
SWITCH-REVERSE LIGHT L04
RADIO FITTINGS N04
REAR FOG LAMPS L14
STARTER AND FIXINGS L06
STOP/TAIL LAMPS L09
SWITCHES-(USA TYPES) M12
LIGHT-WARNING-BRAKE M14
LIGHT-WARNING'FASTEN BELTS M14
LIGHTER ASSEMBLY-CIGAR M14
UNIT-FLASHER M13
UNIT-HAZARD WARNING M14
SWITCHES-RHD M10
LIGHT-BRAKE WARNING M11
LIGHTER ASSEMBLY-CIGAR M11
UNIT-FLASHER-HAZARD WARNING M11
WINDSCREEN WASHER M02
WINDSCREEN WIPERS-LHD L17
WINDSCREEN WIPERS-RHD L15
WIRING CABLES AND FITTINGS M15



MK0183

RADIO FITTINGS

Illus	Part Number	123456	Description	Quantity	Change Point	Remarks
1	DAC	1393	AERIAL ASSEMBLY(LOCKABLE) (WITH 2 KEYS)	1		
	GCA	8088	Key-aerial	1		
2	DZB	5645	Loudspeaker	1		

MASTER INDEX

INTRODUCTION 1 B
ENGINE 1 C
FLYWHEEL AND CLUTCH 1 D
GEARBOX AND PROPSHAFT 1 E
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1 F
STEERING 1 G
BRAKES AND BRAKE CONTROLS 1 H
FUEL, EXHAUST AND EMISSION SYSTEMS 1 I
COOLING, HEATING AND AIR CONDITIONING 1 K
ELECTRICAL, WASHER-WIPERS, INSTRUMENTS 1 L
CHASSIS, SUBFRAMES, BODYSHELL, FITTINGS 2 C
FASCIA, TRIM, SEATS AND FIXINGS 2 E
MISCELLANEOUS 2 F
NUMERICAL INDEX 2 G

GROUP INDEX

ALTERNATOR AND FIXINGS L05
BELT-FAN L05
BATTERY AND FIXINGS N03
COURTESY LIGHTS L13
DISTRIBUTOR-NOT USA L02
DISTRIBUTOR-USA AND CANADA L03
FUSE BOX AND RELAY N02
HEADLAMPS L07
KIT-SCREW-TRIMMER L07
HORN AND CONTROLS M03
INSTRUMENT WARNING LIGHTS M08
INSTRUMENTS M04
LAMP-REFLEX L11
LAMP-REVERSE L10
LAMP-SIDE AND FLASHER L08
NUMBER PLATE LAMPS L12
OIL PRESSURE GAUGE PIPES M09
SWITCH-OIL PRESSURE-ANTI RUN-ON M09
SWITCH-OIL-PRESSURE M09
POWER UNIT ELECTRICS L04
SWITCH-INHIBITOR(SEAT BELT) L04
SWITCH-REVERSE LIGHT L04
RADIO FITTINGS N04
REAR FOG LAMPS L14
STARTER AND FIXINGS L06
STOP/TAIL LAMPS L09
SWITCHES-(USA TYPES) M12
LIGHT-WARNING-BRAKE M14
LIGHT-WARNING FASTEN BELTS M14
LIGHTER ASSEMBLY-CIGAR M14
UNIT-FLASHER M13
UNIT-HAZARD WARNING M14
SWITCHES-RHD M10
LIGHT-BRAKE WARNING M11
LIGHTER ASSEMBLY-CIGAR M11
UNIT-FLASHER-HAZARD WARNING M11
WINDSCREEN WASHER M02
WINDSCREEN WIPERS-LHD L17
WINDSCREEN WIPERS-RHD L15
WIRING CABLES AND FITTINGS M15